



A100E

UK Model

Part 2

Users' Handbook

Part 2

A100E Users' Handbook

Contents

1	Programming PLUs	5
	Changing Prices	7
	Creating And Amending PLUs	8
	Weighed goods	9
	Nonweighed items	13
	Entering Text	17
	Programming keyboards	17
	Creating text	19
	Selecting the size of printed text	20
	Editing text	20
	Inserting text	20
	Recalling text	20
	Correcting the last character displayed	21
	Deleting any other character	21
	Clearing the entire text entered	21
	Deleting PLUs	22
	Deleting The PLU File/Clearing Sales Totals	23
	Setting Up Commodity Keys	24
	At stand-alone and master scales	24
	At slave scales	25
2	Using The DCU	27
	Introducing The C400 DCU	29
	Dumping The PLU File	30
	Loading A PLU File	31
	Deleting A File	33
	Selecting The Mode	35
	Loading Variable Label Formats	36
3	Printing Reports	39
	Running Totals	41
	Grand, group, machine and hourly totals	42
	PLU totals	43
	Clearing Totals - Hourly Figures	45
	PLU File	46
	Security Report	47

System report	47	
Machine report	48	
At stand-alone and master scales		48
At slave scales	49	
Test Report	50	
At stand-alone and master scales		50
At slave scales	51	

4 Programming The A100E 53

Assigning Scroll Messages	55	
Creating Scroll Messages	57	
Entering Group Names	58	
Creating Sales Messages	59	
Setting Up Net Weights	61	
Setting Up Stored Tares	62	
Setting Up A Network	63	
What is a network?	63	
Role of the master scale	63	
Linking up the scales	63	
Copying data to slave scales	64	
Dealing with network faults	66	
Bleeping scale	66	
Replacing a faulty scale	69	

5 Setting Up The A100E 71

Setting Machine Identity	73	
At stand-alone scales	73	
At slave scales	74	
Setting Machine Department	75	
Entering Machine Identity Of On-line Slaves		76
Selecting Label Printout	78	
At stand-alone and master scales		79
At slave scales	80	
Selecting Label Format	81	
At stand-alone and master scales		81
At slave scales	82	
Printing Symbols	83	
At stand-alone and master scales		83
At slave scales	85	
Setting The Date And Time	86	
Entering The Store Name	88	
Setting Up Barcodes	89	
Assigning Barcodes	92	

6	Help Information	95
	Error Messages	97
	If Things Go Wrong	104
7	Quick Reference Charts	105
	X Key Flowcharts	107
	Master and stand-alone scales	107
	Slave scales	108
	Z Key Flowcharts	109
	Master and stand-alone scales	109
	Slave scales	110
	Appendices	111
	1 Standard Label Formats	113
	2 Barcode Format Tables	123

Index

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*