

Avery Weigh-Tronix



Conveyor Scale Installation Manual

Table of Contents

Description	5
Options	5
Features	6
Installation	6
Installation Recommendations	7
Checking Scale Function	8
Operating the Conveyor Scale	8
Balancing Weigh Bars Routed Through a Junction Box	9
Photocells and Connections	10
Photocell Programmable Modules	11
Optional DC Motor Speed Control Wiring	11
Appendix A: WI-110/WI-120 Information	12
Serial ASCII Output	12
Wiring	12
Appendix B: WI-130 Information	15
Setpoints	15
8587A Photocell I/O Installation Configuration	15
Operation	15
WI-130 Main Board I/O Configuration	15
SSCU-8 Remote Expanded I/O Configuration	15
WI-130 to I/O Expansion Board Cable Connections	16
Photocell Connections	16
Appendix C: WI-127 Information	17
WI-127 In-motion wiring	17

Pages are numbered consecutively beginning with the cover page.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/avery berkel/Conveyor Scale installation manual.](https://the-checkout-tech.com/manuals/avery_berkel/Conveyor_Scale_installation_manual/)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)