
DX342
**Price Computing Weighing
Machines**

User Instructions



Contents

1	Installation and set-up	3
1.1	Introduction	3
1.1.1	Symbols	3
1.2	Getting started	4
1.2.1	Installation	4
1.2.2	Switching on	5
1.3	Displays and indicator	7
1.4	Operator keyboard	7
1.5	Routine maintenance	8
1.5.1	Cleaning	8
1.5.2	Changing the batteries	9
2	Weighing	11
2.1	Zeroing the weighing machine	11
2.2	Weighing goods	11
2.3	Using tares	12
2.3.1	Semi auto tare	12
2.3.2	Cumulative tare	13
2.3.3	Keyboard entered tare	14
2.3.4	Retaining a tare	15
2.4	Retaining a unit price	16
2.5	Multiplying a unit price	16
2.6	Using the Add key	17
2.6.1	Weighed goods	17
2.6.2	Non-weighed items	17
2.6.3	Viewing totals	17
2.6.4	Clearing totals	18
2.7	Selecting alternate units	18

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/avery berkel/DX-342 user manual.html](https://the-checkout-tech.com/manuals/avery%20berkel/DX-342%20user%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)