



---

**Table of contents**

Removing the covers	1
Installing expansion boards	2
Installing a head-up display	3
Status display	4
Error messages	5
Configuring the scale	6
Management mode	6
Restricted service access	6
Full service access	7
Verification mode	7
Exiting from full or restricted service access	8
Navigating service mode	9
Product configuration branches	10
Branch 0 - Edit counter	10
Branch 5 - Typical configurations	10
Branch 6 - Weighing functionality	10
Branch 7 - Weighing limits	12
Branch 08 - Gravity compensation	12
Branch 09 - Weight display	13
Branch 19 - Bleeper functions	13
Branch 20 - Power saving	13
Branch 29 - Key press duration	13
Branch 60 - Tares	14
Branch 100 - PLUs	14
Calibration	15
Aborting calibration	16
Replacing a head-up display	17
30kg scales	18
Stiffener plate	18
Base covers	18
Illustrated parts list	19
Head-up display	20
Wiring diagram	21

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*