

IX series Counter Scales



User Instructions

ENGLISH



Contents

page no.

1 Safety

1.1	Warnings	13
	Safe Installation	13
	Safe use	14

2 About Your Machine

2.1	Description	17
2.2	Glossary of symbols used	19
2.3	Installation	20
	Handling	20
	Levelling	20
	Legal requirements	20
2.4	Getting started	21
	Using the documentation	21
	Connections/switch positions	21
	Mains power supply	22
	Solving problems	24
	Battery powered machines	25
2.5	Function keys	26
2.6	Manager mode	28
	Programming menus	29

3 Machine basics

3.1	Creating and editing text	33
	Selecting the size of printed text	33
	Inserting text	34
	Displaying text	34
	Correcting the last character displayed	34
	Deleting a character	34
	Clearing the entire text entered	35
	Extended character set	35
3.2	Setting the date and time	36
3.3	Creating product groups	37

3.4	Setting up the ADD label	38
3.5	Creating messages	41
	Sign on/off text	41
	Store name	41
	Group name	41
	Sales message	42
3.6	Setting up data tables	45
	Tax rate	45
	Tare weight (stored tare)	45
	Discount rates	46
	Discount keys	47
	Payment tables	47
	Payment name	49
3.7	Programming operators	53
	Operator names	53
	Operator PIN	54
	Changing PIN	54
	Security level	54
	Trading or training mode	55
	Operator training text	55
	Operator logging	56
3.8	Setting function security	57
	Security levels	57

4 Programming Products

4.1	Customising the menus	63
4.2	Changing prices	65
4.3	Creating and Editing PLUs	66
	PLU text	68
	PLU display text (16 characters)	69
	PLU text 1 (40 characters)	69
	PLU text 2 (250 characters)	69
	Tax reference	69
	Product groups	69
	Price multiple	70
	Sell by dates/times	70
	Net weights	71
	Proportional tares	71
	Barcode printing	71

4.4	Deleting PLUs	72
4.5	Copying PLUs	73

5 Machine Set-up

5.1	Direct access (Hot) keys	77
5.2	Dedicated keys	78
	Standard keys	79
	ECR (payment) keys	80
	Generic keys	80
5.3	Printer set-up	82
	Label type	82
	Selecting label format	82
	Tare interlock	82
	Suppressing symbols	82
	Selecting print modes	82
	Talon	83
	Duplicate receipt	83
	Single item	84
	Euro print	84
	Machine message	85
5.4	Assigning a barcode format	86
	Trace code	86
5.5	Adjusting the display brightness	87
5.6	Machine operating modes	88
	Floating vendor mode	88
	Point of Sale (PoS) mode	88
	Self-service/pick and mix modes	89
	Operation	91
5.7	Setting alarms	92
	Cash drawer detect	92
	Network error alarm	92

6 Checking programmed data

6.1	Printing data reports	95
	Listing the PLU file	97
	Verify labels	98
	Text report	98

7 Serving Customers

	Operators	101
	Selecting receipt or label mode	101
	Advancing the printer roll	102
7.1	Hand pricing	103
7.2	Using PLUs	104
7.3	Using Tares	105
7.4	Overriding prices	108
7.5	Euro prices	109
	Displaying euro prices	109
	Printing euro prices	109
7.6	Using the FIX key	110
	Receipt mode	110
	Label mode	110
7.7	Voiding a transaction	111
7.8	Returning products	113
7.9	Receipt Operations	115
	Displaying the operator subtotal	115
	Printing a receipt	115
	Counter receipt	115
	Displaying the customers change	116
	Paying for goods	116
	Sales discount	121
	Cash drawer operations	122
	Refunds	123
7.10	Using the ADD key	125

8 Pre-pack Operations

8.1	Using the FIX key.	129
8.2	Using PLUs	131
8.3	Using tares	133
	Free tare	133
	Stored tares	134
	Keyboard entered tare	136
	Proportional tare	137
8.4	Preset tare keys	138
8.5	Multiple labels	139
8.6	Returning labels	141
8.7	Using the ADD key	143

9 Barcodes

9.1	Branded goods	148
	Dry article barcodes	148
	Price embedded barcode	149
9.2	In-store goods	151
	Dry article barcodes	151
	Price embedded barcode	153
9.3	Barcode scanning	155
	Serving customers	155
	Scanner operation	156
9.4	Defining the barcode format	158
9.5	Creating a barcode reference	159
	Receipt barcode	159
	Barcode overflow	160
9.6	Barcode formats	161
	EAN 8	162
	UPC 12	162
	UPC 13	163
	EAN 13	163
	EAN 13 (Scandinavian)	164
	Dry article barcodes	165

10 Product Traceability

10.1	Overview	169
10.2	Operation	170
10.3	Capturing the source data	172
	Counter service operation	173
	Pre-pack operation	174

11 Management Totals

	Configuring reports	179
11.1	Totals reports	180
	Report numbering	180
	Report fields	180
	Grand totals report	182
	Machine totals report	183
	Operator totals report	185
	PLU and group reports	186

	Discount totals report	188
	Security report	189
	Clear All Totals	190
11.2	Carcass totals report	191
11.3	Transaction reports	192
	Print transactions	192
	Clearing transactions	192

12 Communications

12.1	Introducing networking	195
12.2	Setting machine ID	197
12.3	Network map	198
12.4	Dealing with network faults	200
12.5	Local mode	201
	Switching a client to Local Mode	201
	Label machines only	201
	Operating in local mode	202
12.6	Network dump	203

13 The Printer

	Advancing the printer roll	208
	Printer roll dimensions	208
13.1	Changing the printer roll	209
	Changing the label/paper roll	209
	Rewinding the paper	210
13.2	Routine maintenance	212
	Cleaning the print head	212

14 Help

14.1	Set-up mode	217
14.2	Error messages	218
14.3	If things go wrong	222

15 Appendix

15.1	Extended character sets	227
	Roman character set	227
	Greek character set	228

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/avery berkel/IX-100 IX-110 IX-202 IX-212 IX-300](https://the-checkout-tech.com/manuals/avery%20berkel/IX-100%20IX-110%20IX-202%20IX-212%20IX-300)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)