



# M series Retail System Scales

## *Part 1 Operator Instructions*



---

# Contents

*page no*

## **1 Safety**

---

### **1.1 Warnings**

1-1

Safe installation

1-1

Safe use

1-2

## **2 About Your Machine**

---

### **2.1 Description**

2-1

### **2.2 Using the documentation**

2-2

Glossary of symbols used

2-2

### **2.3 Installation**

2-4

Handling

2-4

Levelling

2-4

Non-slip feet

2-4

Legal Requirements

2-5

### **2.4 Getting started**

2-6

Connections/switch positions

2-6

Switching on

2-6

Operator keyboard

2-7

Solving problems

2-7

### **2.5 Function keys**

2-9

## **3 Serving Customers**

---

### **3.1 Basic operations**

3-1

Selecting receipt or label mode

3-1

Printing

3-2

Using the LOG key

3-4

|                                   |      |
|-----------------------------------|------|
| <b>3.2 Hand pricing</b>           | 3-5  |
| Non-weighed items (item price)    | 3-6  |
| <b>3.3 Using PLUs</b>             | 3-7  |
| Using department keys             | 3-7  |
| Promotional PLUs                  | 3-7  |
| Weighed goods                     | 3-8  |
| Non-weighed items                 | 3-9  |
| <b>3.4 Barcode scanning</b>       | 3-10 |
| Checkout mode                     | 3-11 |
| <b>3.2 Displaying euro prices</b> | 3-13 |
| Printing euro prices              | 3-14 |
| <b>3.5 Overriding prices</b>      | 3-15 |
| Weighed goods                     | 3-15 |
| Nonweighed items                  | 3-16 |
| <b>3.7 Voiding a transaction</b>  | 3-17 |
| Checkout mode                     | 3-17 |
| <b>4 Using Tares</b>              |      |
| <hr/>                             |      |
| <b>4.1 Free tare</b>              | 4-1  |
| Cumulative tare                   | 4-2  |
| <b>4.2 Keyboard entered tare</b>  | 4-3  |
| <b>4.3 Preset tare keys</b>       | 4-4  |
| <b>5.2 Paying for goods</b>       |      |
| Printing a sales receipt          | 5-3  |
| Using payment (ECR) keys          | 5-5  |
| Single payment                    | 5-5  |
| Multiple or split payment         | 5-8  |
| Paying with foreign currency      | 5-9  |
| <b>5 Working in Receipt Mode</b>  |      |
| <hr/>                             |      |
| Displaying your operator subtotal | 5-1  |

|                                    |      |
|------------------------------------|------|
| <b>5.1 Printing a receipt</b>      | 5-1  |
| Counter receipt                    | 5-1  |
| <b>5.2 Paying for goods</b>        | 5-3  |
| Printing a sales receipt           | 5-3  |
| Using payment (ECR) keys           | 5-5  |
| Single payment                     | 5-5  |
| Multiple or split payment          | 5-8  |
| Paying with foreign currency       | 5-9  |
| <b>5.3 Customer accounts</b>       | 5-11 |
| Charging to account                | 5-11 |
| Payments received on account       | 5-15 |
| <b>5.4 Sales discount</b>          | 5-18 |
| <b>5.5 Printing euro prices</b>    | 5-20 |
| Printing a euro receipt            | 5-20 |
| <b>5.6 Cash drawer operations.</b> | 5-22 |
| <b>5.7 Refunds</b>                 | 5-28 |
| <b>5.8 Returning products</b>      | 5-30 |
| <b>5.9 Using the FIX key</b>       | 5-33 |
| Weighed goods                      | 5-33 |
| Retaining a unit price             | 5-34 |
| <br>                               |      |
| <b>6 Working in Label Mode</b>     |      |
| <hr/>                              |      |
| <b>6.1 Using the FIX key</b>       | 6-1  |
| Weighed goods                      | 6-1  |
| Retaining a unit price             | 6-2  |
| <b>6.2 Using the ADD key</b>       | 6-4  |
| Weighed goods and nonweighed items | 6-4  |
| <b>6.3 Returning products</b>      | 6-6  |

## 7 Pre-pack Operations

---

|  |      |
|--|------|
| <b>7.1 Setting the machine to pre-pack</b> | 7-1  |
| Using the FIX key                          | 7-2  |
| <b>7.2 Using PLUs</b>                      | 7-3  |
| Weighed goods                              | 7-3  |
| Nonweighed items                           | 7-4  |
| <b>7.3 Using tares</b>                     | 7-5  |
| Free tare                                  | 7-5  |
| Stored tares                               | 7-6  |
| Keyboard entered tare                      | 7-8  |
| Proportional tare                          | 7-9  |
| <b>7.4 Preset tare keys</b>                | 7-10 |
| <b>7.5 Multiple labels</b>                 | 7-11 |
| <b>7.6 Returning labels</b>                | 7-13 |
| <b>7.7 Using the NON ADD key</b>           | 7-15 |
| <b>7.8 Using the REWRAP key</b>            | 7-16 |
| <b>7.9 Using the WRAP key</b>              | 7-18 |
| <b>7.10 Carcass tracking</b>               | 7-19 |

## 8 The Cassette Printer

---

|                                      |     |
|--------------------------------------|-----|
| Advancing the printer roll           | 8-2 |
| Printer roll dimensions              | 8-2 |
| <b>8.1 Changing the printer roll</b> | 8-3 |
| <b>8.2 Routine maintenance</b>       | 8-9 |
| Cleaning the print head              | 8-9 |

## 9 The Receipt (Clamshell) Printer

---

|                            |     |
|----------------------------|-----|
| Advancing the printer roll | 9-1 |
| Printer roll dimensions    | 9-2 |

## Contents

---

|                                      |     |
|--------------------------------------|-----|
| <b>9.1 Changing the printer roll</b> | 9-3 |
| Receipt only printer                 | 9-3 |
| <b>9.2 Routine maintenance</b>       | 9-4 |
| Cleaning the print head              | 9-4 |
| Receipt printer                      | 9-5 |

## Index

---

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*