



WI-127 Indicator Service Manual

Table of Contents

Table of Contents	3
Specifications	4
Introduction	5
Error Messages	5
Service Menu Structure	6
Moving Through Menus	6
Accessing the Menu	7
Exiting the Menu	7
Using the Service Menu	8
About Menu	8
Audit Menu	9
Test Menu	10
J-Box Deadload Offset	10
Setup Menu	12
Top Level of 110 Menu	13
110 Adjust Menu	13
110 Scale Menu	15
Tips on setting up and using the Harmonizer® filtering	18
110 Options Menu	19
110 Serial Menu	20
110 Seal Menu	22
Top Level of 127 Menu	24
127 Adjust Menu	25
127 Scale Menu	26
Tips on setting up and using the Harmonizer® filtering	30
127 Options Menu	31
127 Serial Menu	35
127 BCD Out Menu	36
127 Analog Menu	36
127 Outputs Menu	37
127 Inputs Menu	38
127 Seal Menu	39
127 Transfer Menu	40
Reset Menu / Master Clear	41
Calibrating the WI-127	42
Entering the Calibration Menu	42
Weight Calibration	43
Count Calibration	44
Adding Calibration Points	45
Deleting Calibration Points	45
Customizing the Serial Output	47
Predefined Print Layouts	47
ASCII Strings	50
Step by Step Instructions	52
Entering the Define submenu	52
Creating ASCII strings	53
Creating Layouts	55
Creating Groups	58
Broadcast	59
Autosend	59
Using Inputs and Outputs on the WI-127	60
WI-127 Disassembly and Reassembly	61
Installing Option Cards	62
Inbound/Outbound (GTN) Software	63-78
In-Motion Software	79-90
Technical Illustrations	91
Service Menu	100-102

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/avery berkel/WI-127 service manual.html](https://the-checkout-tech.com/manuals/avery_berkel/WI-127_service_manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)