

# M series Retail System Scales V4.0



## **Part 2**

## **Manager Functions**

ENGLISH



---

# Contents

*page no.*

## **1 Before You Begin**

---

1.1	Keyboard overlay	13
1.2	Manager mode	14
	Programming menus	14
	To enter Manager Mode	15
1.3	Glossary of symbols used	16

## **2 Programming The Machine**

---

2.1	System data	19
	Setting the date and time	19
2.2	Creating departments	20
	Allocating departments	20
	Department keys	21
2.3	Creating product groups	23
2.4	Setting up the ADD label	24
	Pre-pack operation	24
2.5	Information labels	27
2.6	Creating messages	28
	Substitution codes	28
	Scroll message	28
	Store name	28
	Sales message	29
	Date code	29
	Cooking times and loyalty points	30
	Sign on/off text	30
2.7	Creating and editing text	32
	Selecting the size of printed text	32
	Inserting text	33
	Displaying text	33
	Correcting the last character displayed	33
	Deleting a character	34
	Clearing the entire text entered	34
	Extended character set	34
	Remote (IBM type) keyboard	34

2.8	Setting up data tables	35
	Tax rate	35
	Tare weight (stored tare)	36
	Discount rates	36
	Discount keys	37
	Payment tables	38
	Setting up accounts	44
2.9	Printing data reports	47
	Listing the PLU file	49
	Verify labels	50
	Text report	50
2.10	Pack run	52
	Pack run set up	52
	Data names	56
	Displaying and printing subtotals	56
	Deleting pack runs	57
	Pack run lists	57
	Limit change	58
2.11	Setting function security	59
	Security levels	59
	Manager functions	60
2.12	Nutrition facts	61
	Nutrient definitions	61
	Nutrient data texts	62

## **3 Barcodes**

---

	Fixed format barcodes	68
	Variable format barcodes	68
	Printing multiple barcodes	69
3.1	Branded goods	70
	Dry article barcodes	70
	Price embedded barcode	71
3.2	In-store goods	73
	Dry article barcodes	73
	Price embedded barcode	75
3.3	Barcode scanning	77
	Checkout mode	79
	Subtotal and total receipts	79
3.4	Defining the barcode format	80

3.5	Creating a barcode reference	81
	Barcode overflow	82
3.6	Barcode formats	83
3.7	Variable barcode formats	89

## 4 Product Traceability

---

4.1	Overview	93
	Operation	94
	Preset mode	95
	Traceability mode switching	96
	Printing the information	96
4.2	Capturing the source data	97
	Hash key	98
4.3	Programming carcass tables	99
	Creating messages	99
4.4	Setting up the machine	102
	Creating the carcass panel format	102
4.5	Defining the barcodes	105
	Custom barcodes	105
	Carcass barcodes	106
	Scheme emulation	108
	Carcass mode	108
	Receipt carcass	108
	Counter carcass	108
4.6	Carcass code data	109
	Data name	109
	AI codes	110
4.7	Carcass passport	112
4.8	Tray labelling	115
	Setting up the key	115
	Preset mode	116
4.9	Pre-weigh function	117
4.10	Preset carcass mode	118
	Carcass records	118
	Panel text	120
	Carcass panel (batch) keys	121
	Assigning carcass panel keys.	122
4.11	Lot number in PLUs	123
	Enabling PLU lot number	123

	Change lot number	125
	PLU file list	126
4.12	Deleting old carcass panels	127

## **5 Programming Products**

---

	Selecting PLUs by barcode	131
5.1	Customising the menus	131
5.2	Changing prices	133
5.3	Creating and Editing PLUs	134
	Departments	134
	PLUs for dry or branded goods	135
	System prompts	136
	PLU text	138
	PLU display text (16 characters)	138
	PLU text 1 (2000 characters)	138
	PLU text 2 and 3 (2000 characters each)	138
	PLU text 4 (2000 characters)	139
	Tax reference 1 and 2	139
	Product groups	139
	Price multiple	139
	Promotions	140
	Sell by dates	140
	Net weights	141
	Proportional tares	141
	Barcode printing	141
5.4	Deleting PLUs	143
5.5	Copying PLUs	144
5.6	Promotions	145
	Price promotion	147
	Frequent shopper promotion	147
	Weight/item free promotion	147
	Discount promotion	150
	Promo batches	151
	Deleting promo batches	152
	Promo messages	152
5.7	Creating a nutritional panel	154
	Fixed Format	154
	Flexible nutritional panels	155
	Defining the nutritional information	156
	PLU setup	157

---

## 6 Programming Operators

---

6.1	Operator names	164
6.2	Operator PIN	164
	Changing PIN	164
6.3	Security level	165
6.4	Trading or training mode	166
	Operator training text	166
6.5	Operator logging	167

## 7 Machine Set-up

---

7.1	Direct access (Hot) keys	171
7.2	Dedicated keys	172
	Standard keys	173
	Pre-pack keys	174
	ECR (payment) keys	174
	Generic keys	175
7.3	Function keys	176
7.4	Printer set-up	177
	Label setup	177
	Receipt setup	180
7.5	Dual printer operation	185
	Printer configuration	185
	Default configuration	186
	Label formats	186
7.6	Assigning a barcode format	189
	Trace code	189
7.7	Adjusting the display brightness	190
7.8	Machine operating modes	191
	Floating vendor mode	191
	Checkout mode	191
	Point of Sale (PoS) mode	192
	Self-service machines	192
	Setting up the self-service keyboard	194
	Grouping keys	195
7.9	Setting alarms	197
	Cash drawer detect	197
	Network error alarm	197
7.10	Trade transactions (stock mode)	198
	Setting up stock mode	198

7.11	Re-pricing goods	201
	Weigh pack	201
	Totals print	202

## **8 System setup**

---

8.1	System functions	205
	Receipt weight printing	205
	Last subtotal	205
	Prepack PLU lock	205
	Security log level	205
	Sub-total receipts	206
	Customer number	206

## **9 Networks**

---

9.1	Introducing networking	209
	Network compatibility	209
9.2	Operating modes	211
	Counter operation	212
	Customer and system mode	214
9.3	'Auto configure	217
	Adding a machine to the network	217
9.4	Setting machine ID	218
9.5	Network map	219
9.6	Backup server	221
9.7	Dealing with network faults	223
9.8	Local mode	224
	Switching a client to Local Mode	224
	Operating in local mode	225
9.9	Network dump	227
9.10	Machine setup dump	228
9.11	Advanced set-up	229
	Machine IP address	229
	Host name	230
	Gateway IP address	230
	Network ID	230
	Advantage IP address	231
	Host port number	231
	Ping IP test	231

Modem setup	231
Data clone	232
9.12 Wireless LAN communications	233
Ad Hoc (peer to peer) mode	233
Access Point mode	233
Wireless set up	233
Supported network configurations	235
9.13 RF encryption	237
Encryption mode	237
Encryption keys	238
Active key	238
Ethernet disable	238

## **10 Management Totals**

---

10.1	Configuring reports	242
	Reporting period	242
	Report setup	242
	PLU totals	243
	Amount entry	243
	Cash report	243
10.2	Totals reports	244
	Report numbering	244
	Report fields	245
	Grand totals report	247
	Machine totals report	248
	Operator totals report	250
	Hourly totals report	251
	PLU, department and group reports	252
	Discount totals report	254
	Promotion totals report	254
	Security report	256
	Clear All Totals	257
	System cash report	257
10.3	Carcass totals report	259
10.4	Pack run totals	260
	Outstanding Pack runs	260
	Completed pack runs	260
10.5	Transaction reports	262
	Printing transactions	262
	Clearing transactions	262

10.6	Defining filters	263
------	------------------	-----

## **11 Data backup**

---

11.1	Dumping/loading data	267
	System data	267
	Machine data	268
	PLU file	268
	Label formats	268
	Totals dump	269

## **12 Audit mode**

---

12.1	Setting up the audit function	273
	Filtering the information	273
	Server/client buffer mode	273
	Machines in local mode	274
12.2	Printing the audit report	275
12.3	Erase audit list	276

## **13 Help**

---

13.1	Set-up mode	279
13.2	Error messages	280
13.3	If things go wrong	284

## **14 Appendix**

---

14.1	Extended character sets	289
	Roman character set	289
	Greek character set	290
	Lithuanian character set	290
	Latvian character set	291
	Romanian character set	291
14.2	Supported AI codes	292
14.3	Extended substitution codes	293
	Dewey substitution codes	294
	Using Dewey substitution codes	297

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/scales/Avery\\_BerkeI\\_M100\\_M200\\_M202\\_M300\\_M400\\_M410\\_M420\\_M500\\_M600\\_M601\\_M602\\_M603\\_M650\\_M651\\_programming\\_and](https://the-checkout-tech.com/manuals/scales/Avery_BerkeI_M100_M200_M202_M300_M400_M410_M420_M500_M600_M601_M602_M603_M650_M651_programming_and)

Checkout our free online Keysheet Maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

**THE-CHECKOUT-TECH.COM**