



DB-II(LCD) SERVICE MANUAL

(DBB)

< Table of Contents >

1. Introductions	3
1.1. The Preface	3
1.2. Precautions	3
1.3. Specifications	4
1.4. Sealing Method.....	5
2. Calibration Mode.....	6
2.1 How to Go to Normal mode(C - 0)	7
2.2 How to Confirm Span Calibrated A/D Value(C - 1)	7
2.3 Key Test (C - 2).....	8
2.4 Span Calibration(C - 3).....	8
2.5 Capacity Display and Option Setting(C - 4).....	8
2.5.1 Save Setting(C-4-1).....	8
2.5.2 Capacity Setting(C-4-2).....	9
2.5.3 Save Setting(C-4-3)	10
2.5.4 Save Setting(C-4-6)	10
2.6 How to Confirm Real A/D value(C - 5)	11
2.7 How to Confirm Averaging A/D value(C - 6)	11
2.8 % Calibration(C - 7).....	11
2.9 Gravity Constant(C - 9).....	12
2.10 Linearity Compensation(C - 10).....	12
3 The Schematics and Diagram.....	13
3.1 System Block Diagram	13
3.2 Circuit Diagram.....	14
3.3 Wiring Diagram.....	16
3.4 Block diagram software.....	167
3.5 Part Location.....	20
3.6 Exploded View	22
4 Error Message.....	23
5 Serial Interface.....	25
6 Parts List.....	25

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*