



# EC Series

**User manual**

## Table Of Contents

<b>I .</b>	<b>Precautions Before Using The Scale-----</b>	<b>1</b>
<b>II.</b>	<b>Explanation Of Display Symbols-----</b>	<b>2</b>
<b>III.</b>	<b>Keypad Functions-----</b>	<b>4</b>
<b>IV.</b>	<b>Operations-----</b>	<b>5</b>
	(I) Switch on & off-----	5
	(II) Zero the scale -----	5
	(III) Sampling before counting-----	5
	(IV) Preset unit weight in numeric keys -----	8
	(V) Subtract container's weight-----	9
	(VI) Weight/Quantity accumulation-----	14
	(VII) Preset counting check range-----	16
	(VIII) Preset weight check range-----	18
<b>IV.</b>	<b>User Programming Functions-----</b>	<b>20</b>
	(I) Auto. shut off time span-----	20
	(II) Zero Tracking Range-----	21
	(III) Zero display range-----	22
	(IV) Stable class range-----	23
	(V) Stable class rate -----	24
	(VI) Backlight type-----	25
	(VII) Change unit of measure from kg/g to Pound-----	26
	(VIII) Unit weight recomputing-----	27
	(IX) Check alarm type-----	28
	( X ) Baud Rate setting-----	31
	(XI) Transmit method setting-----	32
	(XII) Label format setting (available when a label printer is connected.)-----	33
	(XIII) Cancel Tare setting-----	34
<b>VI.</b>	<b>Calibration (can only be done in kg)-----</b>	<b>35</b>
<b>VII.</b>	<b>Power supply &amp; battery operation-----</b>	<b>36</b>
<b>VIII.</b>	<b>RS-232 Output-----</b>	<b>37</b>
<b>IX.</b>	<b>Error Codes-----</b>	<b>40</b>
<b>X.</b>	<b>Technical Data-----</b>	<b>41</b>

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*