



FW500 SE. SERVICE MANUAL

(Revision 0 / 2013.02.19)

< Table of Contents >

1.	Introduction	2
1.1.	Preface.....	3
1.2.	Precaution.....	3
1.3.	Specifications.....	4
1.4.	Key 오류! 책갈피가 정의되어 있지 않습니다.	
1.5.	Dimension 오류! 책갈피가 정의되어 있지 않습니다.	
1.6.	Sealing Method..... 오류! 책갈피가 정의되어 있지 않습니다.	
2.	Calibration.....	9
2.1.	General Calibration.....	9
2.1.1.	C4 Setting	10
2.1.1.1.	C4-1 Setting.....	10
2.1.1.2.	C4-3 Setting.....	10
2.1.2.	SPAN Calibration Setting (C-3)	11
2.1.3.	Gravity Constant Value Setting (C-9).....	11
2.1.4.	Calibration factor Setting (C-10)	11
2.1.5.	Displaying Real A/D Value (C-5).....	12
2.1.6.	Percent Calibration (C-7)	13
2.1.7.	Battery Calibration (C-8)	13
3.	The Schematics and Diagram	14
3.1.	System Block Diagram.....	14
3.2.	Circuit Diagram	15
3.2.1.	FW500C Main PCB	14
3.2.2.	FW500C Rear Display PCB 오류! 책갈피가 정의되어 있지 않습니다.	
3.2.3.	FW500E Main PCB	16
3.2.4.	FW500E Rear Display PCB	16
4.	Exploded View	20
5.	Load Cell drawing	20
6.	Part Location	21
6.1.	FW500C Main PCB (Top,Bottom)	21
6.2.	FW500E Main PCB (Top,Bottom)	22
6.3.	FW500C Rear Display PCB (Top,Bottom)	23
6.3.	FW500E Rear Display PCB (Top,Bottom)	24
7.	Error Messages & Solution.....	26
8.	Part List.....	27

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*