
CAS HFS SCALE

SERVICE MANUAL(HFS)

TABLE OF CONTENTS

CHAPTER 1 GENERAL INTRODUCTION

- 1 - 1. INTRODUCTION
- 1 - 2. NAME OF EACH PARTS
- 1 - 3. SPECIFICATION

CHAPTER 2 PREPARATION FOR OPERATION

- 2 - 1. PREPARATION FOR OPERATION

CHAPTER 3 INSTALLATION

- 3 - 1. COMPOSITION OF HERCULES FLOOR SCALE

CHAPTER 4 TESTING

- 4 - 1. TOLERANCE LIMIT
- 4 - 2. SENSITIVITY TEST
- 4 - 3. LOAD CELL RESISTANCE TEST
- 4 - 4. FOUR POINT ADJUSTMENT OF LOAD CELL

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/CAS/HFS service manual.html](https://the-checkout-tech.com/manuals/CAS/HFS%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)