

Label Printing Scale

LP 1.6 Series

OWNER'S MANUAL





CONTENTS

PRECAUTIONS	4	4.6 Programming the Shop Data	30
1. Installation Procedures	6	4.7 SET	32
1.1 Cautions	6	4.7.1 Programming the Date (SET #1)	34
1.2 Assembling the Display Pole	6	4.7.2 Programming the Time (SET #2)	35
1.3 Installing the Label Roll	9	4.7.3 Programming the Department Number (SET #3)	36
2. Keypad & Display	11	4.7.4 Programming the Label (SET #4)	37
2.1 Numeric Keypad	11	4.7.5 Programming the Adjust Number (SET #5)	42
2.2 PLU Keypad	12	4.7.6 Programming the Printing Information (SET #6)	43
2.3. Displays	14	4.7.7 Programming the Auto Print Function (SET #7)	45
2.3.1 Weight Display	14	4.7.8 Programming Address (SET #8)	46
2.3.2 Unit Price Display	14	4.7.9 Programming Baud Rate (SET #9)	47
2.3.3 Total Price Display	14	4.8 INT(Initialize PLU and MSG data)	48
2.4. Printer Mechanism	14	4.9 Password	49
3. Operation	16	5. ACCOUNT Mode	50
3.1 REG mode Operations	16	5.1 System Maps	50
3.1.1 Simple Weighing	16	5.2 Print Report	51
3.1.2 How to Use TARE	17	5.2.1 Grand Total	51
3.1.3 Add-up Sales	17	5.2.2 All PLU	52
3.1.4 How to Use PAY Key	18	5.2.3 Individual PLU	52
3.1.5 How to Use FOR Key	19	5.2.4 Non-PLU	53
3.1.6 Multiple Labels	20	5.3 Clearing Sales Data	54
3.1.7 Auto Printing (AUTO MODE)	21	5.3.1 Grand Total	54
4. PROGRAM Mode	22	5.3.2 All PLU	55
4.1 System Maps	22	5.3.3 Non- PLU	55
4.2 PLU Programming	23	5.3.4 All	56
4.3 Preset keys Programming	27	5.4 Printhead Check (CHESS)	57
4.4 Message (Ingredients) Programming	28	6. Error Messages	58
4.5 Programming the Head Data	29	7. Specifications	59
		APPENDIX	60

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*