




OWNER'S Manual


LP-1000N Series

Label Printing Scale



CONTENTS

| | |
|--|----|
| PRECAUTIONS | 5 |
| 1. Installation Procedures | 7 |
| 1.1 Cautions..... | 7 |
| 1.2 Assembling the Display Pole | 7 |
| 1.3 Installing the Label Roll..... | 9 |
| 2. Keypad & Display | 11 |
| 2.1 Numeric Keypad | 11 |
| 2.2 PLU Keypad..... | 12 |
| 2.3. Displays..... | 14 |
| 2.3.1 Weight Display..... | 14 |
| 2.3.2 Unit Price Display | 14 |
| 2.3.3 Total Price Display | 14 |
| 2.4. Printer Mechanism | 14 |
| 3. Operation | 16 |
| 3.1 REG mode Operations..... | 16 |
| 3.1.1 Simple Weighing | 16 |
| 3.1.2 How to Use TARE..... | 17 |
| 3.1.3 How to Use FOR Key..... | 17 |
| 3.1.4 Multiple Labels | 18 |
| 3.1.5 Auto Printing (AUTO MODE) | 19 |
| 4. PROGRAM Mode | 20 |
| 4.1 System Maps | 20 |
| 4.2 PLU Programming | 21 |
| 4.3 Preset keys Programming | 25 |
| 4.4 Message (Ingredients) Programming..... | 26 |
| 4.5 Programming the Head Data | 27 |
| 4.6 Programming the Shop Data..... | 28 |



| | |
|---|-----------|
| 4.7 SET | 30 |
| 4.7.1 Programming the Date (SET #1)..... | 33 |
| 4.7.2 Programming the Time (SET #2)..... | 34 |
| 4.7.3 Programming the Department Number (SET #3)..... | 35 |
| 4.7.4 Programming the Label (SET #4)..... | 36 |
| 4.7.5 Programming the Adjust Number (SET #5)..... | 42 |
| 4.7.6 Programming the Printing Information (SET #6)..... | 44 |
| 4.7.7 Programming the Auto Print Function (SET #7)..... | 46 |
| 4.7.8 Programming the Baud Rate (SET #9)..... | 47 |
| 4.7.9 Programming the SIGNS (SET #10)..... | 48 |
| 4.7.10 Programming the Currency (SET #11)..... | 51 |
| 4.7.11 Set Printer Sensors (SET #12)..... | 54 |
| 4.8 INT (Initialize PLU/MSG data & ¼ and ½ keys) | 59 |
| 5. ACCOUNT Mode | 60 |
| 5.1 System Maps | 60 |
| 5.2 X Report | 61 |
| 5.2.1 Grand Total..... | 61 |
| 5.2.2 All PLU..... | 62 |
| 5.2.3 Individual PLU..... | 62 |
| 5.2.4 Non-PLU..... | 63 |
| 5.3 Z Report | 63 |
| 5.3.1 Grand Total..... | 64 |
| 5.3.2 All PLU..... | 64 |
| 5.3.3 Non-PLU..... | 65 |
| 5.3.4 All..... | 65 |
| 5.4 Printhead Check (CHESS) | 66 |
| 5.5 File Transfer Mode (Trans) | 66 |
| 6. Error Messages | 67 |
| 7. Specifications | 68 |
| 8. Troubleshooting | 68 |
| APPENDIX | 69 |

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*