

REV : 00
JANUARY 2001

ME Series
Magnetic Balance
Service Manual

CAS
CORPORATION

CONTENTS

1. General Introductions	
A. Preface	----- 4
B. Precautions	----- 4
C. Specifications	----- 4
2. Calibration	
A. General span calibration	----- 5
B. Confirmation of setting value (Factory setup)	----- 6
C. Downloading the program code	----- 8
3. The part replacements	
A. Replacement of the sensor	----- 10
B. Correction of the eccentricity	----- 11
C. Calibration	----- 12
D. Replacement of display PCB	----- 12
E. Replacement of main PCB	----- 13
F. Replacement of keypad	----- 14
4. The schematics and the diagram	
A. System block diagram	----- 16
B. Circuit diagram	----- 17
C. Wiring diagram	----- 24
D. Parts locations	----- 25
5. The error messages	
A. Magnetic balance error message	----- 28
B. Interface error message	----- 28
6. PCB trouble shooting	
A. AC adapter	----- 29
B. Power check point	----- 30
C. Reference check point	----- 31
D. Restore check point	----- 31
E. Temperature compensation part I check point	----- 32
F. Temperature compensation part II check point	----- 33

G. Optical part check point	-----	33
H. Analog to digital converter part check point(weighing)	-----	34
I . Analog to digital converter part check point(temp.)	-----	34
J. Digital part check point	-----	35
K. Display part check point	-----	35
7. Interface		
A. RS232C connection	-----	36
B. Printer specifications	-----	36
8. Parts list		
A. Parts list (PCB)	-----	37
B. ME210,310,410 Sensor Ass'y	-----	41
C. ME210,310,410 Final Ass,y	-----	42
D. ME210,310,410 Sensor Ass'y	-----	43
E. ME210,310,410 Final Ass,y	-----	45

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*