


Crane Scale

NC Series

OWNER'S MANUAL





CONTENTS

PRECAUTIONS	4
PREFACE	6
NAMES AND FUNCTIONS	6
1. OVERALL VIEW	6
2. DISPLAY	6
3. KEY FUNCTIONS	7
OPERATIONS	7
1. POWER ON	7
2. ZERO OPERATION	7
3. TARE OPERATION	8
4. UNIT CONVERSIONS	9
ERROR MESSAGES	9
1. ERROR 1	9
2. ERROR 3	9
3. OVER LOAD	10
4. ERROR BEEP	10
THE PROGRAMS	10
1. TO SELECT MOTION BAND	10
2. TO SELECT DIGITAL FILTER	11
3. TO SELECT AUTO-POWER OFF INTERVAL	11
4. TO SET E.L. ON OR OFF	12
BATTERY OPERATION	13
1. CHARGE	13
2. BATTERY OPERATING TIME	14
3. LOW BATTERY("BAT.") SIGNAL	14
REMOTE CONTROL	14
1. REMOTE CONTROLLER OPERATION	14
2. REPLACING BATTERY IN REMOTE CONTROLLER	14
ASSEMBLE AND DISASSEMBLY	15
SPECIFICATIONS	16

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/CAS/NC Series owner manual.html](https://the-checkout-tech.com/manuals/CAS/NC%20Series%20owner%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)