

Service Manual – PB Series REV NO : 2

PB Series

Service Manual

LAST Rev. NO : 2

LAST Rev. Date : 2009. 06. 10

Table of Contents

1. Proper Operation / Introduction	3
1.1. Preface.....	3
1.2. Precaution.....	3
2. Classification	4
2.1. Overall View.....	4
2.2. Display Pad (Key Pad).....	4
2.2.1. PB(Basic).....	4
2.2.2. PB(Full Option).....	오류! 책갈피가 정의되어 있지 않습니다.
3. Getting Started.....	5
3.1. Sealing Method.....	5
4. Calibration Mode	6
4.1. General Calibration	6
4.1.1. C4 Setting	7
4.1.1.1. C4-1 Setting.....	7
4.1.2. SPAN Calibration Setting (C-3)	8
4.1.3. Gravity Constant Value Setting (C-9)	8
4.1.4. Calibration factor Setting (C-10).....	8
4.1.6. Percent Calibration (C-7).....	9
4.1.7. Battery Calibration (C-8)	10
5. Servicing & Parts Replacement	10
5.1. Trouble Shooting.....	10
5.2. Error Message.....	11
6. Options Installing.....	11
6.1. Serial Interface(RS-232C).....	11
7. Update.....	12
7.1. ROM Download Method	12
8. Exploded Views & Parts List	15
8.1. Exploded View	15
8.2. Loadcell Ass'y.....	17
8.3. Main PCB Ass'y (Top).....	18
8.4. Main PCB Ass'y (Bottom).....	18
8.5. Display Ass'y.....	오류! 책갈피가 정의되어 있지 않습니다.
8.6. Scale Ass'y.....	오류! 책갈피가 정의되어 있지 않습니다.
9.Revision	20

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/CAS/PB Series service manual.html](https://the-checkout-tech.com/manuals/CAS/PB%20Series%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)