
Road Weigher

MODEL : RW Series(S/L TYPE)

SERVICE MANUAL





* * * Table of Contents * * *

1.	Introduction	••••••		1
2.	Feature			2
3.	Technical Specific	ation		3
	Overview			
	Dimension			
	Specification			
	Product			
RW & Serial Print Connection				
4.	Connection for So	ales		4
5.	Charging	•••••		8
6.	Front Panel Desci	iption		9
7.	Test Mode			11
8.	Set Mode			13
9.	Installation	••••••		17
10.	. HOW TO WEIGH VEHICLE			18
11.	Error Message and			20
	Trouble Shooting]		20
12.	Calibration Mode	}		21
13.	Part Arrangement	••••••		25
14.	Schematic Diagram	n		27
15.	PART LIST	••••••		28
16.	EXPLODE VIEW	••••••	•••••	33

This is a "Table of Contents preview" for quality assurance

The full manual can be found at http://the-checkout-tech.com/estore/catalog/

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<u>http://the-checkout-tech.com</u> : the biggest supplier of cash register and scale manuals on the net