
SW SERIES

SERVICE MANUAL

C A S CORPORATION

THE CONTENTS

CHAPTER-I THE GENERAL INTRODUCTIONS

A...PREFACE	3
B...THE PRECAUTIONS	3
C...SPECIFICATIONS	4
D...SEALING METHOD	5

CHAPTER-II THE CALIBRATIONS

A...SET THE CALIBRATION MODE	6
B...HOW TO DISPLAY THE A/D VALUE	6
C...SPAN CALIBRATION	7
C.1..SPAN CALIBRATION	7
C.2..PERCENT CALIBRATION	8
C.3..TO CONFIRM THE SPAN AND TO DO FINE TRIMMING	8
D...HOW TO RETURN TO NORMAL MODE	9

CHAPTER-III THE PART REPLACEMENTS

A...REPLACEMENT OF THE LOAD CELL	10
A.1..REPLACEMENT OF THE LOAD CELL	10
A.2..CORRECTION OF THE ECCENTRICITY	10
A.3..THE SPAN CALIBRATION	10

CHAPTER-IV THE SCHEMATICS AND THE DIAGRAMS

A...MAIN CIRCUIT DIAGRAM	11
B...REAR CIRCUIT DIAGRAM	12
C...WIRING DIAGRAM	13
D...PARTS LOCATION	15

CHAPTER-V THE ERROR MESSAGES

A...THE ERROR MESSAGES	18
------------------------	----

CHAPTER-VI FULL PARTS LIST

A...EXPLODED VIEW	19
B...FULL PARTS LIST	20

APPENDIX – DEVICE SPECIFICATION

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/CAS/SW-Series service manual.html](https://the-checkout-tech.com/manuals/CAS/SW-Series%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)