

REV : 00

May 03, 2002

# **TP-II SERIES**

**Service Manual**

**CAS CORPORATION**

THE GENERAL INTRODUCTIONS .....	3
A. PREFACE .....	3
B. THE PRECAUTIONS .....	3
C. SPECIFICATIONS .....	4
D.OPTION.....	4
E.SEALING METHOD.....	5
THE CALIBRATIONS .....	6
A.SET THE CALIBRATION MODE.....	7
A.1 CALIBRATION FLOW CHART .....	7
<b>A.2 GRAVITY CONSTANT</b> .....	8
A.3 SPAN CALIBRATION.....	8
A.4 PERCENT CALIBRATION.....	9
A.5 TO CONFIRM THE SPAN AND TO DO FINE TRIMMING .....	10
A.4 HOW TO RETURN TO NORMAL MODE .....	11
THE PART REPLACEMENT .....	12
A. REPLACEMENT OF THE LOAD CELL.....	12
A.1 REPLACEMENT OF THE LOAD CELL.....	12
A.2 CORRECTION OF THE ECCENTRICITY .....	12
A.3 THE SPAN CALIBRATION.....	12
SOFT KEY SETUP.....	13
A.    INPUT FOR THE SOFT KEY CODES .....	13
A.1 HARDWARE KEY.....	13
A.2 SOFTWARE KEY .....	13
B.INPUT FOR WEIGHING CONDITION CODES .....	14
THE SCHEMATICS AND THE DIAGRAMS .....	15
INTERFACE.....	29
A. THE COMMUNICATION AGREEMENTS .....	29
A.1 THE PROTOCOL.....	29
A.2 THE WIRE CONNECTIONS.....	30
PARTS LIST & EXPLODED VIEW .....	31

---

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/CAS/TP-II-Series service manual.html](https://the-checkout-tech.com/manuals/CAS/TP-II-Series%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)