



CSW-20AT INDICATOR



SETUP & OPERATION MANUAL

CAMBRIDGE SCALE WORKS, INC.
5011 HORSESHOE PIKE
PO BOX 670
HONEY BROOK, PA. 19344

PH: 800-292-7640
FX: 610-273-3612

www.cambridgescale.com

TABLE OF CONTENTS

Meter connections -----	3
1.0 Operation -----	4
1.1 Key Functions -----	4 - 5
1.2 Error Messages -----	6
2.0 Scale Procedure -----	7
2.1 Software Navigation Flowchart -----	7 - 8
2.2 Scale Menu Definitions -----	9 - 11
3.0 Calibration Procedure -----	12
3.1 Calibration Menu Definitions -----	12
3.2 Calibration -----	13
3.3 Linearity Correction -----	13
3.4 Quick Calibration -----	14
3.5 Quick Calibration Linearity correction -----	14
4.0 Communications Setup -----	15
4.1 Communications Menu Definitions -----	14 - 21
5.0 Testing Procedure -----	22
5.1 Testing Menu Definitions -----	22
6.0 Troubleshooting -----	23-24
7.0 Warranty -----	25
8.0 Assistance -----	26

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*