



## CSW-20AT-B INDICATOR



## SETUP & OPERATION MANUAL

CAMBRIDGE SCALE WORKS, INC.  
5011 HORSESHOE PIKE  
P.O. BOX 670  
HONEY BROOK, PA 19344

PH: 800-292-7640  
FX: 610-273-3612

[www.cambridgescale.com](http://www.cambridgescale.com)

MANUAL P/N: 5999-1035-00 (03/11)

# TABLE OF CONTENTS

Meter connections -----	3
1.0 Operation -----	4
1.1 Charging the battery -----	4
1.2 Key Functions -----	5 - 6
1.3 Error Messages -----	6
2.0 Scale Procedure -----	7
2.1 Software Navigation Flowchart -----	7 - 8
2.2 Scale Menu Definitions -----	9 - 11
3.0 Calibration Procedure -----	11
3.1 Calibration Menu Definitions -----	11
3.2 Calibration -----	11 - 12
3.3 Linearity Correction -----	12
3.4 Quick Calibration -----	12
3.5 Quick Calibration Linearity correction -----	13
4.0 Communications Setup -----	13
4.1 Communications Menu Definitions -----	13 - 19
5.0 Testing Procedure -----	20
5.1 Testing Menu Definitions -----	20
6.0 Troubleshooting -----	21-22
7.0 Warranty -----	23
8.0 Assistance -----	23

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*