

## OPERATION MANUAL

MODEL:

DC-120

DIGI MATEX, INC.

80 DAK STREET NORWOOD, NJ 07648 201-784-3400 FAX: 201-784-3770 PEDITION

	MONTH	YEAR
IST	SEPTEMBER	1989
2ND		
3RD		
4TH		
57H		
5TH		
7TH		
8TH		
9TH		
IOTH		

## DC-120 SERIES OPERATING MANUAL

## INDEX

SECTI	ON	<u>F</u>	AGE	NUMBER
1.0	GENERA	L		1
	1.1	Description		
	1.2	Warranty		
2.0		ICATIONS		2
		Capacities		
	2.2	Technical		
3.0	INSTALLATION			5
	3.1	Unpacking		
		Inspection		
		Repacking		
	3.4	Unlocking Procedure		
4.0		ICAL TEST		8
		Set-Up Procedure		
	4.2	Keyboard & Display Test		
5.0		OPERATIONAL PROCEDURES	:	11
	5.1	DC-120 Operation		
		DC-120 Keyboard Layout		
		Key Switch Information		
		Indicator Lamp Information		
	5.2	Message List		
	5.2	DC-120 Procedure for Determining		
	5.3	an Unknown Unit Weight DC-120 Parts Counting		
	5.4	DC-120 Accumulation		
	5.5	DC-120 Setpoints		
	5.6	Parts "In-Out" Operation		
	0.0	Tares III out operación		
6.0	PROGRAI		2	20
	6.1			
	6.2	To Check or Change Memory Data for an Item		
	6.3	To Delete Items from Memory		
		Sample Programming Form		
7.0		OPTIONAL EQUIPMENT	2	24
	7.1	Bar Code Input		
	7.2	RS-232 Communications Port		
	7.3	DP-80 Printer		
	7.4	Set Point Outputs		
	7.5	Digital Tape Back Up		
8.0		NANCE, CALIBRATION, TEST PROCEDURE & SERVICE	2	29
	8.1	Maintenance Procedures		
	8.2	Service & Repair		

This is a "Table of Contents preview" for quality assurance

The full manual can be found at <a href="http://the-checkout-tech.com/estore/catalog/">http://the-checkout-tech.com/estore/catalog/</a>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<u>http://the-checkout-tech.com</u>: the biggest supplier of cash register and scale manuals on the net