



DC-150

Counting Scale

Operation Manual

SECTION 1. OPERATION MODE – TABLE OF CONTENTS		PAGE
1.0	GENERAL	3
1.0.1	DESCRIPTION	3
1.1	MODE FLOW CHART	4
1.2	SPECIFICATION	5-7
1.3.1	OVERALL VIEW	8 & 9
1.3.2	DISPLAY & KEYS	10
1.3.3	KEY FUNCTION IN OPERATION MODE	11-13
1.4	LABEL FORMAT AND LABEL SET UP	14 - 15
1.5	GENERAL EXPLANATION OF SHELF LOCATION & SET POINT	16 - 17
1.5.3	UNLOCKING PROCEDURE	18
1.5.3	SOFTWARE VERSION RECALL	19
1.5.7	UNIT WEIGHT ENTRY BY SAMPLING	20
1.5.8	UNIT WEIGHT ENTRY BY NUMERIC KEYS	21
1.6	TARE WEIGHT ENTRY	22
1.6.1	ONE TOUCH TARE ENTRY	22
1.6.2	TARE ENTRY BY NUMERIC KEYS	22
1.7	PART NO. ENTRY	23
1.8	PART NAME	23
1.9	LOT NO. ENTRY	24
1.9.2	PRINTER TURN OFF/ON	24
1.10	SEQUENCE NO. ENTRY	25
1.11	ID CODE ENTRY	25
1.12	PARTS COUNTING OPERATION	26
1.12.1	SINGLE TRANSACTION	26
1.12.2	MULTIPLE TRANSACTION	27
1.13	BATCH LABEL PRINT	28
1.14	SELECTING LABEL FORMAT	29
1.14.1	ADDRESS DATA ENTRY	29
1.15	GROSS WEIGHT DISPLAY	30
1.16	AUTO JOB OPERATION MODE	31 - 31

SELECTION 2	PROGRAM MODE TABLE OF CONTENTS	PAGE
2.1	HOW TO ENTER PROGRAM MODE	33
2.2	KEY FUNCTION IN PROGRAM MODE	34
2.3	ID PROGRAMMING	35
2.3.1.	ID CODE DATA STORAGE IN MEMORY	36
2.3.2.	PROGRAMMING ID CODE ITEM DATA	37-43
2.3.3.	DELETION OF PROGRAMMED ID CODE AND ITEM DATA	44
2.4	DATE AND TIME PROGRAMMING	45
2.5	SETPOINT OUTPUT PROGRAMMING	46
2.6	FIELD TITLES PROGRAMMING	47
2.6.1.	LABEL GRID	48
2.6.2.	PROGRAMMING FIELD TITLES	49
2.6.3.	DELETION OF PROGRAMMED FIELD TITLES	50
2.7	PRE - PRINT PROGRAMMING OF VENDOR NAME	51
2.7.1.	PRE-PRINTED PROGRAM FIELD	51
2.7.2.	PROGRAMMING FOR PRE - PRINT NAMES	52-53
2.7.3.	DELETION OF PRE - PRINT CONTENTS	54
2.7.4.	PRINT POSITION AND CHAR. SIZE OF PRE-PRINT NAME	55
2.7.4.1.	PRINT POSITION	55
2.7.4.2.	CHARACTER SIZE AND MAGNIFICATION	55
2.7.4.3.	DISPLAY AND PROGRAMMING SCREEN	56
2.7.4.4.	PROGRAMMING FOR PRE - PRINT COORDINATE	56-57
2.8	COPY OF STANDARD FORMAT (FORMAT - COPY)	58
2.9	FREE FORMAT PROGRAMMING	59
2.9.1	TYPE OF LABELS	59
2.9.2.	LABEL SIZE	59
2.9.3.	CUSTOM FREE FORMAT SAMPLE LABEL	60-61
2.9.4.	PROGRAMMING DATA FOR EACH LABEL	62
2.9.5.	PRINTING POSITION	63
2.9.6.	LABEL ANGLE AND BAR-CODE ANGLE	64
2.9.7.	DATA TYPE	65
2.9.8.	LABEL FORMAT GRID LAYOUT CHART	66-67
2.9.9.	PROGRAMMING SCREEN	68-69
2.9.10.	KEY FUNCTION	69
2.9.11.	PROGRAMMING OPERATION	70-74
2.9.13.	PROGRAMMING PROCEDURE (USING COPY FUNCTION)	75-76
2.10	SHELF LOCATION LABEL PROGRAM	77
2.10.1.	LABEL SIZE	77
2.10.2.	PROGRAMMABLE ITEM DATA	77
2.10.3.	PRINT POSITION	77
2.10.4.	LABEL ANGLE AND BAR-CODE ANGLE	78
2.10.5.	CHARACTER SIZE AND MANIFICATIONS	78
2.10.6.	DATA TYPE	78
2.10.7.	PROGRAMMING SCREEN	78-79
2.10.8.	PROGRAMMING PROCEDURE	79
2.10.9.	PROGRAM PROCEDURE	818
2.11	SHELF LOCATION LIMIT PROGRAM	82
2.12	ADDRESS CONTENTS PROGRAM	82-83
2.12.1.	PROGRAMMING OPERATION FOR ADDRESS CONTENTS	82-83
2.12.2.	DC-150 ADDRESS DATA BASE	83-84
2.12.3.	DELETION OF PROGRAMMED DATA	84

SECTION 3	MAINTENANCE MODE TABLE OF CONTENTS	PAGE
3.1	HOW TO ENTER MAINTENANCE MODE	87
3.2	KEY FUNCTONS IN MAINTENANCE MODE	88
3.3	SET SPEC CODES	89-108
3.4	MEMORY DELETE	109-110
3.5	PRINT ADJUSTMENT	111
3.5.1.	FEED VALUE	111-112
3.5.2.	DETECTION LEVEL	112-113
3.5.3.	PRINT CONTRAST	113-114
3.6	AUTO JOB PROGRAMMING	115
3.6.1.	PROGRAMMABLE PROCESS IN AUTO JOB OPERATION	115
3.6.2.	PROGRAMMING SCREEN	116
3.6.3.	PROGRAMMING OPERATION	116
3.7	DATA TRANSFER	117-119
3.8	MODEM COMMUNICATION	120
3.8.1.	PROGRAMMING OPERATON AT AUTO SIDE	120
3.8.2.	MANUAL PROGRAMMING OPERATON	121-122
3.9	PRINTING OPERATION	123-124

SECTION 4	CHECK MODE TABLE OF CONTENTS	PAGE
4.1	MEMORY FILES	126
4.1.1.	OPERATION TO PRINT ALL ITEMS REPORT	127
4.1.2.	OPERATION TO PRINT ONE ITEMS REPORT	127-128
4.31.3.	OPERATION TO PRINT GROUP ITEM REPORT	128
4.2	MOVEMENT & THRESHOLD REPORT	129
4.2.1.	OPERATON TO PRINT TODAY'S MOVEMENT REPORT	129
4.2.2.	OPERATON TO PRINT THRESHOLD REPORT	130
4.3	SHELF LOCATION LABEL PRINT	131
4.4	MEMORY FILE OUTPUT TO PC	132

5.0 SPECIFICATION LIST

5.1 PC/AT ALPHANUMERIC KEYBOARD	page 136
5.2 BARCODE SCANNER SETUP	page 137 - 139
5.3 RS - 232 COMMUNICATIONS	page 140 - 143
5.4 SET - POINT OUTPUT	page 144 - 145
5.5 MODEM COMMUNICATIONS	page 146 - 157

6.APPENDIX

Sample Label Formats and Bar Code labels

6. 1 Format Layout	page	II
6. 2 Format Layout	page	III
6. 3 Format Layout	page	IV
6. 4 Format Layout	page	V
6. 5 Format Layout	page	VI
6. 6 Format Layout	page	VII
6.7 Format Layout	page	VIII
6.8 Format Size & Magnification	page	IX
6.9 Bar Code Print Size	page	X
6.10 Print Orientation	page	XI
6.11 Sample Inventory Reports	page	XII - XIII

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*