



Operation Manual for DC-788

Prepared : 8 July 2003
1st Amendment: : 11 November 2004

1. General Layout	4
2. Purpose	5
3. Features.....	5
4. Operating Conditions	5
5. Charging Conditions (for Rechargeable battery only).....	5
7. Display and Indicators.....	6
7.1. Display Specifications.....	6
7.2. Indicators.....	6
8. Dimensions	6
9. External Connectors	7
10. Main Components	7
11. Existing parts to be used.....	7
12. Keysheet Layout.....	8
13. Key Functions.....	8
14. Notable differences from current Teraoka scales:	9
15. Block Diagram of Electrical Connection	9
16. Physical layout of Electrical Connection	10
17. Hardware Description.....	11
17.1. Microcomputer.....	11
17.2. Pin Assignment.....	11
18. Maintenance Mode	Error! Bookmark not defined.
18.1. SPAN Adjustment.....	Error! Bookmark not defined.
18.2. Escape from Maintenance mode	Error! Bookmark not defined.
18.3. Specification Setting	Error! Bookmark not defined.
18.3.1. Specification Enter (141).....	Error! Bookmark not defined.
18.3.2. Specification Enter (142).....	Error! Bookmark not defined.
18.4. Internal Count & A/D Count Display	Error! Bookmark not defined.
18.5. Operational Specification List	Error! Bookmark not defined.
19. Operations In Weighing Mode.....	13
19.1. ON/OFF	13
19.2. Tare Subtraction.....	13
19.2.1. One Touch Tare Subtraction	13
19.2.2. Digital Tare Subtraction	13
19.3. Unit Weight Entry Operation.....	13
19.3.1. By Sampling.....	13
19.3.2. Digital Unit Weight Operation.....	14
19.4. Insufficient Sampling Weight Operation	14
19.4.1. Add Samples	14
19.4.2. Adopt Suggestion	14
19.4.3. Ignore Suggestion.....	14
19.5. Parts Counting Operation.....	15
19.5.1. Single Counting Operation.....	15
19.5.3. Negative Counting Function	15
19.6. Net/Gross Operation	16
19.7. Item Code Call Up	17
19.7.1. Recall Numeric Item Code.....	17
19.7.2. Recall Alphanumeric Item Code	17
Memory Field of Item Code.....	17

20. Operations In Program Mode	18
20.1. Program Item Code	18
20.2. Delete Item Code in Memory.....	19
20.2.1. Delete a Certain Item Code	19
20.2.2. Delete all Item Code.....	19
20.2.3. Delete all Inventory Value from Memory	19
20.2.4. Delete all Unit Weight Value from Memory.....	19
20.2.5. Delete all Tare Weight Value from Memory	20
20.2.6. Delete all Parts Numbers from Memory	20
20.2.7. Delete all Setpoint Data from Memory	20
20.2.8. Delete all Parts Name from Memory	20
20.2.9. Reset Sequence Number to 0.....	21
20.3. Review Item Code.....	21
20.4. Program Setpoint to Operate all Items	21
20.5. Date and Time	21

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/Digi/DC-788 operation manual.html](https://the-checkout-tech.com/manuals/Digi/DC-788%20operation%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)