



# DI-10

*Check Weighing Scale*

# Operation Manual

# DI-10 OPERATION MANUAL

SECTION	CONTENTS	PAGE NUMBER
<b>1.0.</b>	<b><u>GENERAL</u></b>	<b>2-5</b>
1.1.	DESCRIPTION	2
1.2.	APPEARANCE	3
1.3.	DISPLAY & KEYS	4
1.4.	INDICATOR LAMPS	5
<b>2.0.</b>	<b><u>INSTALLATION</u></b>	<b>6-9</b>
2.1.	UNPACKING	6
2.2.	INSPECTING	6
2.3.	REPACKAGING	6
2.4.	UNLOCKING (DIGI GRAND)	6-8
2.5.	DI-10 POLE ASSEMBLY	9
<b>3.0.</b>	<b><u>SPECIFICATIONS</u></b>	<b>10-15</b>
3.1.	CAPACITIES	10
3.2.	TECHNICAL	11
3.3.	SET-UP PROCEDURE	12-13
3.4.	FEATURES	14-15
<b>4.0.</b>	<b><u>OPERATION INSTRUCTION.</u></b>	<b>16-24</b>
4.1.	POWER ON	16
4.2.	ONE TOUCH TARE	17
4.3.	DIGITAL TARE	18
4.4.	DIGITAL TARE WHILE WEIGHING	19
4.5.	SET POINTS	20-21
4.6.	ADDITION AND SUBTRACTION	22
4.7.	COUNTING.	23
4.8.	NET/GROSS DISPLAY	23
4.9.	DATE & TIME SETTING	24
4.10.	LB/KG CONVERSION	24
<b>5.0.</b>	<b><u>DI-10 OPTIONAL EQUIPMENT</u></b>	<b>25-30</b>
5.1.	PRINTER	25
5.2.	SETPOINT OUTPUT.	26-27
5.3.	RS-232C DATA OUT	28-30
5.4.	AC/DC ADAPTOR.	30
<b>6.0.</b>	<b><u>MAINTENANCE, CALIBRATION, TEST PROCEDURE &amp; SERVICE</u></b>	<b>31-39</b>
6.1.	MAINTENANCE PROCEDURES	31-32
6.2.	SERVICE & REPAIR	32
6.3.	PLATFORM WIRING	32
6.4.	ERROR MESSAGE LIST	33
6.5.	SPEC. LIST	34-36
6.6.	CALIBRATION	37-38
	NOTES:	39

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/Digi/DI-10 operation and calibration manual.html](https://the-checkout-tech.com/manuals/Digi/DI-10%20operation%20and%20calibration%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)