



# DS-160

*Bench Scale*

# Service Manual



<b>Section</b>	<b>Table of Contents</b>		<b>Page</b>
<b>1.</b>	<b>Features</b>		<b>2</b>
	1.1.	Unlocking Procedure	2
<b>2.</b>	<b>Specifications</b>		<b>3</b>
<b>3.</b>	<b>Set-up Procedure</b>		<b>4 – 8</b>
	3.1.	Initial Set-up Procedure	4
	3.2.	Start-up	4
	3.3.	SPEC Data Setting for RS-232C	4
	3.4.	SPEC Data Setting for W & M	5
	3.5.	How to Set/Change SPEC Data	5
	3.6.	SPEC Data List	6
	3.7.	Weight Calibration	8
<b>4.</b>	<b>Machine Operation</b>		<b>9– 10</b>
	4.1.	Key Functions	9
	4.2.	Sign Lamps	9
	4.3.	Zero Setting	9
	4.4.	One-touch Tare Weight Reduction	9
	4.5.	Digital Tare Weight Reduction	10
	4.6.	Error Display	10
	4.7.	Quick Maintenance Operation Table	11
<b>5.</b>	<b>RS-232C Data Output</b>		<b>12</b>
<b>6.</b>	<b>Disassembling</b>		<b>15</b>
<b>7.</b>	<b>Electrical Distribution</b>		<b>16</b>
<b>8.</b>	<b>Shop Notes</b>		<b>17</b>

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/Digi/DS-160 service manual.html](https://the-checkout-tech.com/manuals/Digi/DS-160%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)