



DS-160

Bench Scale

Service Manual



Section	Table of Contents		Page
1.	Features		2
	1.1.	Unlocking Procedure	2
2.	Specifications		3
3.	Set-up Procedure		4 – 8
	3.1.	Initial Set-up Procedure	4
	3.2.	Start-up	4
	3.3.	SPEC Data Setting for RS-232C	4
	3.4.	SPEC Data Setting for W & M	5
	3.5.	How to Set/Change SPEC Data	5
	3.6.	SPEC Data List	6
	3.7.	Weight Calibration	8
4.	Machine Operation		9– 10
	4.1.	Key Functions	9
	4.2.	Sign Lamps	9
	4.3.	Zero Setting	9
	4.4.	One-touch Tare Weight Reduction	9
	4.5.	Digital Tare Weight Reduction	10
	4.6.	Error Display	10
	4.7.	Quick Maintenance Operation Table	11
5.	RS-232C Data Output		12
6.	Disassembling		15
7.	Electrical Distribution		16
8.	Shop Notes		17

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*