



DS-425

Bench Scale

Installation/Service Manual

DS - 425 OPERATION MANUAL

INDEX

<u>SECTION</u>		<u>PAGE</u>
1.0	<u>GENERAL</u>	1-5
	1.1. Warranty And Limitation Of Liability	I
	1.2. Appearance	1-2
	1.3. Model Specification	2-3
	1.4. Key Layout & Function	3
	1.5. Display Layout & Function	4
2.0	<u>INITIAL SET-UP</u>	5-6
	2.1. Unlocking	5
	2.2. Location Of Span Switch	6
3.0	<u>OPERATION</u>	7-11
	3.1. System On/Off	7
	3.2. Tare	7
	3.3. Gross And Net Weight Conversion	8
	3.4. Weight Unit Change	8
	3.5. Counting Operation	8
	3.6. Set-point	9-11
4.0	<u>MAINTENANCE</u>	12-16
	4.1. Check Status Of Span Switch	12
	4.2. Calibration	12
	4.3. Customer Specification Setting	13
	4.4. Weights & Measures Specification Setting	13
	4.5. View Internal Count	14
	4.6. Software Specification List	14-15
	4.7. System Display Information (Error Messages)	16

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*