



SERVICE MANUAL

Model: DS-425

Edition	Month	Year
1 st	September	1998
2 nd	December	1998
3 rd	April	2001
4 th	January	2002

Shanghai Teraoka Electronic Co., Ltd. --- Technical Service Dept.
Ting Lin Industrial Development Zone Jin Shan District, Shanghai P. R. China 201505
Tel: +86-21-5723-4888 Fax: +86-21-5723-9330 E- mail: steservice@digi-scale.com

CONTENTS

1. General Specification	
1.1. Overall Dimension	1
1.2. Display Panel	1
1.3. Main Feature	2
1.4. Operation Condition	2
1.5. Main Function	2
1.6. Layout And Function	3
2. Initial Set-Up	
2.1. Stopper Screws	4
2.2. Adjustment	5
2.3. Location of the SPAN SW	5
2.4. Span Switch Check	6
2.5. Span Adjustment	6
2.6. Specification Setting	7
2.7. Internal Count and A/D Count Display	8
2.8. Specification List (*V1.04)	8
2.9. System Display Information	10
3. Main Operation	
3.1. System On	11
3.2. One Touch Tare	11
3.3. Digital Tare Operation.....	11
3.4. Gross / Net Display Toggle	12
3.5. Weight Unit Conversion	12
3.6. Counting Operation	12
3.7. Set-Point Setting	13
3.8. Set-Point Alarm Function	14
4. RS-232C Protocol	
4.1. Communication Specs	16
4.2. Communication Text Command	16
4.3. Data Format	16
4.4. Communication Method	17
5. Hardware Specification	
5.1. Main Components	19
5.2. Block Diagram.....	19
5.3. Electronic Connection Diagram	19

Note: Circuit Diagram on page 20 is missing

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/Digi/DS-425 service manual.html](https://the-checkout-tech.com/manuals/Digi/DS-425%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)