

Specifications and Operation Manual for DS-673

Prepared : 1 January 2007
1st Amendment : 20 June 2007

1. General Layout.....	3
2. Purpose.....	4
3. Features	4
4. Operating Conditions	4
5. Charging Conditions	4
6. Analog Specification.....	4
7. Capacity/Minimum Graduation/Tare range	5
7.1. Single Interval.....	5
7.2. Multi-Interval	5
8. Display and Indicators	5
8.1. Display Specifications.....	6
8.2. Indicators.....	6
9. Dimensions.....	6
10. External Connectors.....	6
11. Main Components	6
12. Existing parts to be used	6
13. Keysheet and Key Functions.....	6
13.1. Keysheet Layout	6
13.2. Key Functions	6
14. Notable differences from current Teraoka scales:	6
15. Block Diagram of Electrical Connection	7
16. Physical layout of Electrical Connection	8
17. Hardware Description	9
17.1. Microcomputer.....	9
17.2. Pin Assignment	9
18. Maintenance Mode.....	11
18.1. Software Version and Span Switch State check	11
18.2. SPAN Adjustment.....	11
18.3. Escape from Maintenance mode	11
18.4. Specification Setting	12
18.5. Internal Count & A/D Count Display	12
18.6. Operational Specification List.....	13
19. Operations In Weighing Mode.....	14
19.1. ON/OFF.....	14
19.2. Reset and Weighing Check	14
19.3. Tare Subtraction	14
19.4. Automatic Shut-Off Timer Setting.....	15
19.5. Display Dimmer Setting.....	15
19.6. kg and lb Conversion.....	15
19.7. kg, decimal lb and kati Conversion	16
19.8. Set Default Weight Unit	16
20. Error Message List.....	16

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : the biggest supplier of cash register and scale manuals on the net