




DS-688F USER'S GUIDE



DISPLAY & KEYBOARD PANEL



- | OPERATION KEYS | FUNCTIONS |
|----------------|--------------------------------------|
| ① On/Off Key | Turns the power on or off. |
| ② Preset Keys | Set up or call unit price. |
| ③ Numeric Keys | Input numerical values. |
| ④ Tare Key | Sets or clears tare value. |
| ⑤ Clear Key | Clears numerical values. |
| ⑥ Re-zero Key | Resets weight display to zero. |
| ⑦ Mode Set Key | Enters into Preset and program mode. |
| ⑧ * Key | NOT IN USE. |


- | INDICATORS | |
|---------------------|---|
| ⑨ Zero Indicator | Lights on when zero point is adjusted and weight is stable. |
| ⑩ Net Indicator | Lights on when tare subtraction is effective. |
| ⑪ Battery Indicator | Lights on when battery is weak and needs to be charged |
| ⑫ Level Indicator | Used for Level Adjustment. |

Note: Operation Keys and Indicators may differ in certain countries.

PRE-OPERATION

1) Level Adjustment

- Place scale on firm and flat base.
- Level the scale by turning adjusting legs until air bubble is at the center of the level indicator.



2) Power supply

- When the AC Power cable is plugged in and the optional battery is built-in, DS-685F works with the AC power.
- When the optional battery is built-in, but the AC Power cable is not plugged in, DS-685F can be operated with the battery.
- The battery will be automatically re-charged when the AC Power cable is plugged in, whether or not the ON/OFF switch is on.

Note: With the fully charged battery, DS-688F can be operated for 8 hours. And 18 hours are needed for full-recharging.

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*