


DIGI® DIGI LITE USER'S GUIDE

1. DISPLAY & KEYBOARD PANELS



1-1 INDICATORS

- 1 ZERO : Lights on when zero point is adjusted.
- 2 TARE : Lights on when net weight is displayed. (Tare value is subtract)
- 3 BATT : Lights on when battery power is low.

1-2 KEY FUNCTIONS

- 4 REZERO/TARE key : Reset weight to zero / set or clear a tare value.
- 5 MODE key : Convert weight between g / lb / oz/lb&oz.
- 6 ON/OFF key : Turn power ON or OFF.

2. PRE-OPERATION

- ① Fix the plastic platter support to the scale body and stainless steel platter o support.
- ② Put 4 pieces of AA size battery into the battery holder which in the bottom o scale.
- ③ Place scale on firm and flat place and keep the scale in level.

3. OPERATION CONDITION

- ① Power : 4 pieces of AA size dry battery or AC/DC adaptor (6V/100mA)
- ② Operation Temperature: 0-40°C (32 °F-104 °F)
- ③ Operation Humidity: <85%RH

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/Digi/Lite operation manual.html](https://the-checkout-tech.com/manuals/Digi/Lite%20operation%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)