



# OPERATION MANUAL

---

*MODEL : SM-110*

---

◆ EDITION

	<i>Month</i>	<i>Year</i>
<i>1<sup>st</sup></i>	<i>January</i>	<i>2008</i>
<i>2<sup>nd</sup></i>	_____	_____
<i>3<sup>rd</sup></i>	_____	_____
<i>4<sup>th</sup></i>	_____	_____

---

**SHANGHAI TERAOKA ELECTRONIC CO., LTD**  
**TECHNICAL SUPPORT DEPARTMENT**

3rd Floor of 2nd Building, Jia Yuan Business Center,  
51# Long Wu Road, Shanghai China 200232.

TEL : +86-21-6408-5151

FAX : +86-21-6408-3468

EMAIL ADDRESS : steservice@digiscale.com

---

# Table of Content

<b>1. GENERAL</b> .....	<b>1</b>
1.1 Overall View .....	1
1.2 Display Panel .....	3
1.3 Key Panel .....	3
1.4 Thermal Printer Head .....	8
1.5 Features .....	9
1.6 Specifications .....	10
1.6.1 Display .....	10
1.6.2 Operating Conditions .....	10
1.6.3 Dimensions .....	10
1.7 Label Type.....	11
<b>2. INITIAL SETUP</b> .....	<b>12</b>
2.1 Setup .....	12
2.2 Location of Switches and Connectors.....	14
2.3 Mode Change.....	14
2.4 Memory Initialization .....	15
2.5 Specification Setting .....	15
2.6 Password Setting.....	16
2.6.1 Procedures of Password Setting.....	16
2.6.2 Password Using.....	16
2.7 Clear Files.....	17
<b>3. PROGRAM MODE</b> .....	<b>18</b>
3.1 Programmable Files .....	18
3.2 General Explanation.....	19
3.3 Department Files .....	20
3.3.1 Program Department File .....	20
3.3.2 Delete Department File.....	21

3.4 Main Group Files.....	22
3.4.1 Program Main Group File.....	22
3.4.2 Delete Main Group File.....	23
3.5 Program / Skip Item Data .....	24
3.6 PLU Programming .....	26
3.6.1 Program PLU File(weighing item) .....	30
3.6.2 Program PLU File(non-weighing item).....	33
3.6.3 PLU [COPY] Function.....	37
3.6.4 Delete PLU File.....	38
3.6.5 Volume Discount & Mark Down print function.....	39
3.7 Memory Status.....	41
3.8 Key Assignment.....	42
3.8.1 PLU Assignment.....	42
3.8.2 Function Key Assignment.....	42
3.8.3 Delete Preset Key Assignment .....	43
3.9 Shop Name File.....	44
3.9.1 Program Shop Name File .....	44
3.9.2 Delete Shop Name File .....	45
3.10 Advertisement File .....	46
3.10.1 Program Advertisement File.....	46
3.10.2 Delete Advertisement File.....	47
3.11 Vender File.....	48
3.12 Program Date And Time.....	49
3.13 Special Message File .....	50
3.13.1 Program Special Message File .....	50
3.13.2 Delete Special Message File.....	51
3.14 Ingredient File .....	52
3.14.1 Program Ingredient File.....	52
3.14.2 Delete Ingredient File.....	53
3.15 Text File .....	54
3.15.1 Program Text File.....	54

3.15.2 Delete Text File.....	55
3.16 Free Format File .....	56
3.16.1 General Information.....	56
3.16.2 Print Area, Print Position and Print Angles.....	57
3.16.3 Programming Parameter Of Print Items.....	59
3.16.4 Free Format Entry.....	61
3.16.5 Free Format Copy Function.....	66
3.16.6 Free Format Delete Function.....	66
3.16.7 Sample of program a format by modifying the existing format .....	67
3.17 Place File .....	70
3.17.1 Program Place File .....	70
3.17.2 Delete Place File.....	70
3.18 Machine Setting.....	71
3.19 Logo File .....	72
3.19.1 Pre-programming Logo Data.....	72
3.19.2 Program Display & Keys Function.....	73
3.19.3 Programming Order.....	74
3.19.4 Program Logo File.....	74
3.19.5 Delete Logo File .....	75
3.20 Tax File.....	76
3.20.1 Program Tax File.....	76
3.20.2 Delete Tax File .....	77
3.21 Scroll Message File .....	78
3.21.1 Program Scroll Message File .....	78
3.21.2 Delete Scroll Message File.....	78
3.22 Scroll Sequence File.....	79
3.22.1 Program Scroll Sequence File.....	79
3.22.2 Enable or Disable Scroll Sequence File .....	80
3.22.3 Delete Scroll Sequence Number.....	81
3.23 ASCII Character Input Method.....	82
3.24 ASCII Code Input Method.....	83

- 4. REGISTRATION MODE ..... 84**
- 4.1 ON/OFF ..... 84
- 4.2 Reset and Weighing Check..... 84
- 4.3 Tare Subtraction..... 85
  - 4.3.1 One touch Tare Subtraction .....85
  - 4.3.2 Digital tare Subtraction.....85
- 4.4 PLU Call Up ..... 86
  - 4.4.1 Manual PLU Call Up .....86
  - 4.4.2 PLU Call Up by Preset Key.....86
  - 4.4.3 PLU Call by Numeric Key (Auto PLU Call) .....86
- 4.5 Fix Operation ..... 87
  - 4.5.1 Fix Tare by FIX Key.....87
  - 4.5.2 Fix PLU by FIX Key .....87
  - 4.5.3 Fix Unit Price by FIX Key.....87
- 4.6 Operation Mode Change ..... 88
- 4.7 Item Label Printing in Manual Mode ..... 89
  - 4.7.1 Label Printing for PLU Item.....89
  - 4.7.2 Label Printing for NON-PLU Item.....90
- 4.8 Total Label Printing in Manual Mode ..... 91
  - 4.8.1 Sales Transaction .....91
  - 4.8.2 [PRICE DISCOUNT] Function Key in Add Mode.....92
  - 4.8.3 [PRICE % DISCOUNT] Function Key in Add Mode.....92
- 4.9 Data Correction..... 93
  - 4.9.1 On The Spot Correction .....93
  - 4.9.2 Void by Item Correction.....94
- 4.10 Item Label Printing in Pre-pack Mode ..... 95
  - 4.10.1 Item Label Issue for PLU Item.....95
  - 4.10.2 Item Label Issue for NON-PLU Item.....96

- 5. READ REPORT MODE ..... 97**
- 5.1 Report Factor Select..... 97
- 5.2 Report Type Selection..... 97
  - 5.2.1 Main Group Report.....99
  - 5.2.2 PLU Report .....99
  - 5.2.3 Department Report.....100
  - 5.2.4 Sales Report .....101
  - 5.2.5 24Hour Report.....101
  - 5.2.6 ABC Report.....101
  - 5.2.7 Clerk Report.....102
  - 5.2.8 Pre-pack Report.....103
  - 5.2.9 Tax Report.....104
  - 5.2.10 Store Summarized Report.....104

**6. RESET REPORT MODE .....105**

**7. Apendix .....106**

- A. Specification List
- B. Flexible Barcode Setting Guide
- C. Traceability Setting Guide
- D. Nutrition Setting Guide
- E. Operational Menu Tree

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*