DIGI

SM300 QUICK STEPS

Contents:

- 1. Glossary of terms
- 2. Legend of symbols
- 3. To print labels
- 4. Subtracting days from the packed on date
- 5. Turning off the packed on date
- 6. Turning the packed on date back on
- 7. Subtracting days from the best before date
- 8. Changing the best before date
- 9. Turning off the best before date
- 10. Turning the best before date back on
- 11. To attach ingredients to a PLU
- 12. Adding or changing a PLU
- 13. To delete a PLU
- 14. To change prices permanently
- 15. To program weekly specials
- 16. To delete special price change batch
- 17. To assign preset key page

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store:

https://the-checkout-tech.com/manuals/Digi/SM-300 quick guide manual.html

And our free Online Keysheet maker:

https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM