

Model PC-500 Portion Control Scale



Technical Manual

Doran Scales, Inc.
1315 Paramount Pkwy
Batavia, IL 60510
1-800-262-6844
www.doranscales.com
MAN0266 Revision 0.1

Table of Contents

<u>Section 1. Unpacking and Installation</u>	1
Unpacking:.....	1
Installation:.....	1
Electrical Connections:.....	1
Care & Cleaning:.....	1
<u>Section 2. Scale Operations Guide</u>	3
Display Functions:.....	3
Basic Weighing:.....	3
Units Select:.....	3
Low Battery:.....	3
Power:.....	3
Automatic Sleep Function:.....	3
<u>Section 3. Setup and Calibration Guide</u>	4
Optional AC Power Connection:.....	4
Optional RS-232 Connection:.....	4
Optional Remote Zero Switch:.....	5
Calibration and Parameter Setup:.....	6
<u>Section 4. Parameter Setup</u>	8
Entering and Exiting Setup Mode:.....	8
Changing Start up Units:.....	8
Legal for Trade Restrictions:.....	8
<u>Section 5. Setup Menus Explained</u>	9
Resolution Setup Menu.....	9
Capacity Setup Menu.....	9
Calibration Menu(s).....	9
Reset All Parameters to Default Settings?.....	9
Auto Off Mode.....	10
Operation Mode.....	10
Auto Zero Tracking.....	10
Motion Aperture.....	10
Start Up Zero.....	11
Data Output.....	11
Data Format.....	12
Baud Rate.....	12
Units Enabled.....	12
Startup Units.....	13
Raw Counts.....	13
<u>Section 6. Data Communications</u>	14
Remote Scale Commands:.....	17
<u>Section 7. Specifications</u>	18
<u>Section 8. Troubleshooting</u>	19
General problem resolution:.....	19
Error Messages:.....	20

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*