

GSE Model 250

Digital Indicator



Technical Reference Manual
Version 1.1

Table of Contents

1.	INTRODUCTION	3
1.1.	Overview	3
1.2.	Approvals (for trade versions only).....	3
1.3.	The Manuals Set	3
1.4.	Document Conventions	4
2.	SPECIFICATIONS.....	5
3.	INSTALLATION	6
3.1.	Introduction	6
3.2.	General Warnings	6
3.3.	Electrical Safety	6
3.4.	Cleaning	6
3.5.	Panel Mount Template	6
3.6.	Cable Connections.....	6
3.7.	DC Power (DC PWR + , DC PWR –)	7
3.8.	Load Cell Connection.....	7
3.8.1.	Load Cell Signals and Scale Build	7
3.8.2.	4-Wire Connection	7
3.8.3.	6-Wire Connection	8
3.9.	Auxiliary Connections.....	8
3.9.1.	RS-232 Serial.....	8
3.9.2.	Remote Input	9
3.9.3.	Outputs	10
3.10.	GSE-LINK (Optional).....	10
3.11.	Connecting Shields	11
3.11.1.	Cable Shield Connection and Earthing	11
3.12.	Regulatory Sealing Requirements	11
4.	DATA ENTRY.....	12
4.1.	Editing Annunciators	12
4.2.	Numeric Entry	12
4.3.	Selections and Options	12
5.	BASIC OPERATION	14
5.1.	Display and Controls	14
5.1.1.	Front Panel: Visual Display	14
5.2.	Operation Keys	15
5.2.1.	Primary Function	15
5.2.2.	Editing Function	15
5.3.	Stability Considerations.....	15
5.4.	POWER Key	15
5.4.1.	Automatic Operation	15
5.5.	ZERO Key	15
5.6.	TARE Key	16
5.7.	GROSS/NET Key.....	16
5.7.1.	GSE-LINK Activation.....	16
5.8.	PRINT Key	16
5.9.	FUNCTION Key	16
6.	CONFIGURATION ISSUES	17
6.1.	General Setup Information	17
6.2.	Basic Weighing Terminology.....	17
6.3.	Filtering Techniques	18
6.4.	Industrial vs OIML and NTEP Modes	18
6.5.	Calibration Counter	18
6.6.	Passwords.....	19
6.6.1.	Full Setup Password	19
6.6.2.	Safe Setup Password	19
6.6.3.	Setup Lock-Out	19
7.	SETUP.....	20
7.1.	Accessing Setup	20
7.1.1.	Setup Display Prompts	20

7.2.	Exiting Full or Safe Setup.....	20
7.3.	Groups and Items.....	21
7.3.1.	GRP (Group).....	21
7.3.2.	ITM (Item).....	21
7.4.	Setup Menus.....	21
7.4.1.	BUILD (Scale Build).....	21
7.4.2.	OPTION (Scale Options).....	22
7.4.3.	CAL (Scale Calibration).....	23
7.4.4.	SPEC (Special Settings Menu).....	23
7.4.5.	SERIAL (Serial Communications Options).....	25
7.4.6.	SET.PTS (Setpoint Settings).....	25
7.4.7.	CLOCK (Clock Settings).....	26
7.4.8.	TEST (Special Test Functions).....	26
7.4.9.	FACTRY (Factory Adjustment Menu).....	27
7.4.10.	– End – (Leaving Setup).....	27
8.	CALIBRATION.....	28
8.1.	Performing a Digital Calibration with Test Weights.....	28
8.1.1.	ZERO (Zero Calibration Routine).....	29
8.1.2.	SPAN (Span Calibration Routine).....	29
8.2.	Performing a Calibration with Direct mV/V Entry.....	29
8.2.1.	DIR.ZER (Direct Zero Calibration Entry).....	29
8.2.2.	DIR.SPN (Direct Span Calibration Entry).....	29
8.3.	Using Linearization.....	29
8.3.1.	ED.LIN (Edit Linearization Points).....	30
8.3.2.	CLR.LIN (Clear linearization).....	30
9.	SERIAL OUTPUTS.....	31
9.1.	Automatic Weight Output.....	31
9.2.	Master Serial Output.....	32
10.	SETPOINTS.....	33
10.1.	Setpoint Connection.....	33
10.2.	Setpoint Operation.....	33
11.	SPECIAL FUNCTIONS.....	34
11.1.	Introduction.....	34
11.2.	Key Functions.....	34
11.2.1.	NONE.....	34
11.2.2.	TEST.....	34
11.2.3.	COUNT.....	34
11.2.4.	UNITS.....	34
11.2.5.	HOLD and PEAK HOLD.....	34
11.2.6.	LIVE.WT.....	35
11.2.7.	SHOW.T.....	35
12.	APPENDIX.....	36
12.1.	Dimensions.....	36
12.2.	Sealing Details.....	37
12.3.	Setup Menu Quick Reference.....	38
12.4.	Error Messages.....	39
12.4.1.	Weighing Errors.....	39
12.4.2.	Setup and Calibration Errors.....	39
12.5.	Diagnostic Errors.....	40
12.6.	Glossary Terms.....	40
12.7.	List of Figures.....	41
12.8.	List of Tables.....	41
13.	INDEX.....	42

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/GSE/250 technical reference manual.html](https://the-checkout-tech.com/manuals/GSE/250%20technical%20reference%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)