

# *GSE*

## Model 355, 465 and 562 Check Weighers



## **Users Guide**

Version 1.0



# Table of Contents

<b>CHAPTER 1: INTRODUCTION .....</b>	<b>1</b>
SPECIFICATIONS .....	1
<b>CHAPTER 2: INSTALLATION.....</b>	<b>3</b>
OUT OF BOX SETUP .....	3
STACK LIGHT OPTION INSTALLATION .....	3
<i>Model 355 Installation</i> .....	4
<i>Wiring the Stack Light</i> .....	6
<i>Model 465 Installation</i> .....	7
<i>Model 562 Installation</i> .....	9
<b>CHAPTER 3: MODEL 355 SETUP .....</b>	<b>11</b>
INTRODUCTION.....	11
<i>Display</i> .....	11
<i>Keypad</i> .....	12
CHECKWEIGHING METHOD EXAMPLES .....	12
SETUP .....	16
<i>Access Checkweighing Methods</i> .....	16
<i>Enter Target and Limits in the Setup Mode</i> .....	16
<i>Save the Changes</i> .....	16
<i>Enter Target Value and Limits From the Weigh Mode</i> .....	17
PARTS COUNTING.....	17
<i>Enable Count Mode (Quantity)</i> .....	18
<i>Save the Changes</i> .....	18
<i>Counting Methods</i> .....	18
<b>CHAPTER 4: MODEL 465 SETUP .....</b>	<b>19</b>
<i>Display</i> .....	19
<i>Keypad</i> .....	19
CHECKWEIGHING METHOD CHOICES.....	20
<i>Fixed Limit</i> .....	20
<i>% of Targ</i> .....	20
STATUS INDICATION .....	21
OPERATING MODE CHOICES.....	22
<i>NET MODE</i> .....	22
<i>GROSS MODE</i> .....	22
<i>COUNT MODE</i> .....	22
SETUP (F1) .....	23
<i>View Method and Operating Mode</i> .....	23

<i>Set Method and Operating Mode</i> .....	23
SET TARGET AND LIMITS (TARGET) .....	24
<i>Enter a Known Target Value</i> .....	24
SET A PASSWORD CODE .....	25
PRODUCT ID .....	25
<i>Quick Recall by ID Number:</i> .....	25
<i>Recall by Product ID or Product Name:</i> .....	26
<b>CHAPTER 5: MODEL 562 SETUP</b> .....	<b>27</b>
DISPLAY .....	27
KEYPAD .....	27
PARAMETER MAP .....	28
SET TARGET (F1) .....	29
<i>Enter a Known Target Value</i> .....	29
SETUP MODE (F2) .....	30
<i>Operating Mode (1)</i> .....	30
<i>Over / Under Target (2)</i> .....	32
<i>Display Style (3)</i> .....	33
<i>Based On (4)</i> .....	34
PRODUCT ID (F3) .....	35
<i>Access an Existing Product ID</i> .....	36
SET TARGET OR UNDER/OVER LIMITS .....	37
SET A PASSWORD CODE .....	37
<b>CHAPTER 6: CALIBRATION</b> .....	<b>39</b>
MODEL 355 CHECKWEIGHER .....	39
<i>Access Calibration</i> .....	39
<i>Performing Calibration</i> .....	39
<i>Establishing Zero</i> .....	39
<i>First Zero</i> .....	40
<i>Last Zero</i> .....	40
<i>False Zero</i> .....	41
<i>Only Zero</i> .....	42
<i>Reset Calibration</i> .....	43
<i>Exiting Calibration</i> .....	44
MODEL 465 AND 562 CHECKWEIGHER .....	46
<i>Performing Calibration</i> .....	46
<i>Establishing Zero</i> .....	46
<i>New Zero</i> .....	46
<i>Last Zero</i> .....	47
<i>Temp Zero?</i> .....	48
<i>Only Zero?</i> .....	48
<i>Cal Reset</i> .....	49
<i>Exiting Calibration</i> .....	50

<b>CHAPTER 7: ERROR CODES .....</b>	<b>51</b>
MODEL 355 .....	51
MODEL 465 AND 562.....	55

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*