

Wedge Reference Guide

OVERVIEW	3
INSTALLATION.....	3
CONNECTING WEDGE TO AN INDICATOR:.....	3
TOOLBAR: FILE.....	4
TOOLBAR: DATABASE EXPLORER.....	5
TOOLBAR: TOOLS	5
TOOLBAR: HELP.....	6
HELP..SEND FEEDBACK	6
HELP..WEDGE USER GUIDE.....	7
HELP..ABOUT	7
SUMMARY WINDOW	8
SET UP A SERIAL INDICATOR.....	9
RS232.....	9
RS485	10
SET UP AN ETHERNET CONNECTION.....	10
RETRIEVING A SERIAL NUMBER FROM AN INDICATOR.....	12
RECEIVING DATABASES	12
VIEWING DATABASE	14
MANIPULATING DATABASE	15
EXPORT DATA	15
IMPORT DATA.....	16
SENDING A DATABASE	17
DATABASE ERRORS	19
DATA COLLECTION	19
SETTING UP DATA COLLECTION FOR AN INDICATOR.....	19

Wedge Reference Guide

DATA FORMAT	21
ENABLE DATA LOGGER.....	22
DATA TEMPLATE	22
START DATA COLLECTION.....	23
STOP DATA COLLECTION	24
WEDGE ACTIVEX CLIENT.....	24
CONTROL TOOLBOX.....	25
ACTIVEX CONTROLS.....	26
VIEW CODE	28
SAMPLE VBA CODE FOR EXCEL & ACCESS:	29
<i>Sample VBA Code for Excel:.....</i>	<i>30</i>
<i>Sample VBA Code for Access:.....</i>	<i>31</i>

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/GSE/60 Series Wedge reference guide manual.pdf>

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)