

---

AIRLINE BAGGAGE SCALE

# *ABS 4100*

Technical Reference Manual 2.0



***scale  
systems***

# CONTENTS

<b>CHAPTER 1: INTRODUCTION</b> .....	<b>1</b>
CONVENTIONS AND SYMBOLS.....	1
DISPLAY .....	2
<i>Annunciators</i> .....	2
KEYPAD .....	3
KEYPAD FUNCTIONS.....	3
SPECIFICATIONS.....	5
<b>CHAPTER 2: INSTALLATION</b> .....	<b>7</b>
MOUNTING.....	7
<i>Load Cell Connections</i> .....	10
<i>Serial Port Connections</i> .....	11
<b>CHAPTER 3: ABS 4100 CONFIGURATION</b> .....	<b>15</b>
SETUP MODE .....	15
SELECTION PARAMETERS.....	18
KEY-IN PARAMETERS.....	19
PARAMETER MAP.....	20
<i>Parameter Map Details</i> .....	22
CUSTOM TRANSMIT SETUP .....	28
<i>Elements of a Custom Transmit</i> .....	28
<i>Writing a custom transmit ASCII text file</i> .....	28
<i>Accessing Setup and Clearing Existing Custom Transmit</i> .....	28
<i>Entering ASCII Text</i> .....	29
<i>Entering ASCII Control Codes</i> .....	29
<i>Exiting Setup Mode and Saving Changes</i> .....	32
<i>Display Capture Utility</i> .....	33
GENERAL SETUP AND OPERATION .....	34
<i>Baggage Weighing and accumulation</i> .....	35
RS-485 MULTI-DROP NETWORK SETUP AND OPERATION.....	36
<i>Setup</i> .....	36
<i>Operation</i> .....	36
<i>Network Protocol</i> .....	37
<b>CHAPTER 4: CALIBRATION MODE</b> .....	<b>39</b>
SETUP MODE CALIBRATION .....	39
FAST CALIBRATION .....	39
PERFORMING CALIBRATION .....	40
<i>Establishing Zero</i> .....	40

<i>Establishing Span</i> .....	46
<i>Exiting Calibration</i> .....	46
<b>CHAPTER 5: LEGAL-FOR-TRADE.....</b>	<b>49</b>
NTEP REQUIREMENTS.....	49
OIML REQUIREMENTS.....	49
OTHER REQUIREMENTS.....	50
SEALING AND AUDIT TRAILS.....	50
<i>Physical Seal</i> .....	51
<i>Audit Trails</i> .....	52
<b>CHAPTER 6: ABS 4100 OPTION.....</b>	<b>55</b>
RS-485 NETWORKING.....	55
<i>Network Connections</i> .....	56
<b>CHAPTER 7: TROUBLESHOOTING.....</b>	<b>60</b>
ERROR MESSAGES .....	60
<i>Operational Errors</i> .....	60
<i>Setup Mode Errors</i> .....	61
<i>Hardware Errors</i> .....	62
<i>Calibration Errors</i> .....	62
<i>Communication Errors</i> .....	63
<i>Miscellaneous Errors</i> .....	63
VIEWING SETUP .....	63
INFORMATION MODE PARAMETERS .....	64
A/D CALIBRATION PROCEDURE .....	66

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*