



## **CS1500 Users Manual**

**Intercomp Co.  
3839 County Road 116  
Minneapolis, MN 55340 U.S.A.**

**(763)-476-2531**

**1-800-328-3336**

**Fax: 763-476-2613**

**[www.intercompcompany.com](http://www.intercompcompany.com)**

Manual#: 700000-S

# Table of Contents

<b>INTRODUCTION .....</b>	<b>3</b>
SPECIFICATIONS .....	3
<i>Controls</i> .....	3
<i>Electrical</i> .....	3
<i>Performance</i> .....	3
<i>Environmental</i> .....	3
<i>Physical</i> .....	4
WEIGHTS AND MEASURES .....	5
OPTIONAL EQUIPMENT.....	5
<b>OPERATIONS.....</b>	<b>6</b>
OPERATING PRACTICES.....	6
DISPLAY .....	7
CONTROLS .....	8
<i>ON</i> .....	8
<i>OFF</i> .....	8
<i>ZERO</i> .....	8
<i>Lb/Kg</i> .....	9
<i>TARE Set/Display</i> .....	9
<i>PRINT</i> .....	10
<i>MODE</i> .....	11
REMOTE CONTROL .....	12
POWER/BATTERIES .....	13
<b>MAINTENANCE.....</b>	<b>14</b>
PERIODIC INSPECTION.....	14
<i>Service Categories</i> .....	14
<i>Inspection Requirements</i> .....	14
<i>Removal from Service Criteria</i> .....	15
CALIBRATION.....	15
<i>How to test the calibration</i> .....	15
<i>How to enter a number</i> .....	16
<i>Calibration switch</i> .....	17
<i>How to calibrate the scale</i> .....	17
<i>Weight calibration</i> .....	22
LEGAL-FOR-TRADE SEALING .....	22
<b>TROUBLESHOOTING .....</b>	<b>23</b>
<b>PARTS AND ACCESSORIES.....</b>	<b>25</b>
PARTS LIST: 250 LB, 500 LB CAPACITY .....	26
PARTS LIST: 1K LB - 20K LB CAPACITY.....	28
<b>ERROR MESSAGES .....</b>	<b>29</b>
<b>SERIAL OUTPUT (OPTIONAL).....</b>	<b>30</b>
SCOREBOARD .....	30
PRINTER TICKET .....	33
<b>HOW TO REACH INTERCOMP SERVICE.....</b>	<b>34</b>

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*