



TL6000 Tension Link Users Manual

**Intercomp Co.
3839 County Road 116
Minneapolis, MN 55340**

(763)-476-2531

1-800-328-3336

Fax: 763-476-2613

<http://www.intercompcompany.com/>

Manual #: 700169-L

Table of Contents

INTRODUCTION	3
SPECIFICATIONS.....	3
<i>Controls</i>	3
<i>Electrical</i>	3
<i>Performance</i>	3
<i>Environmental</i>	3
<i>Radio</i>	4
OPERATIONS.....	5
OPERATING PRACTICES.....	5
DISPLAY	6
CONTROLS	7
<i>ON/OFF</i>	7
<i>MODE</i>	7
PRINT.....	8
UNITS.....	8
SET P1, SET P2, Audio Alarm (optional).....	8
SAMPLE RATE	9
SLEEP	9
AUTO OFF.....	10
SERIAL DATA OUT.....	10
BAUD RATE.....	10
ANALOG OUT.....	11
SCALE ID.....	11
<i>ZERO</i>	11
<i>TARE</i>	12
<i>PEAK</i>	12
POWER/BATTERIES	12
MAINTENANCE.....	13
PERIODIC INSPECTION.....	13
<i>Service Categories</i>	13
<i>Inspection Requirements</i>	13
<i>Removal from Service Criteria</i>	14
CALIBRATION.....	14
<i>How to test the calibration</i>	14
<i>How to enter a number</i>	15
<i>Calibration Strap</i>	15
<i>How to calibrate the scale</i>	16
<i>Calibrating the weight accuracy</i>	18
ERROR MESSAGES	19
TROUBLESHOOTING	19
SERIAL OUTPUT.....	20
SCOREBOARD	21
HOW TO REACH INTERCOMP SERVICE.....	22

"This document is the property of Intercomp Co. It contains material and information that is confidential and protected under federal and/or state trade secret, unfair competition, and copyright law. Any reproduction, use or disclosure without written permission from Intercomp Co. is prohibited".

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*