## AC-2000 PLU SCALE PROGRAMMER MANUAL

Description	<u>Page</u>	
General	1	
Programming Keyboard Functions	2 - 3	
Key Switch Functions	3	•• •
Full Programming Menu Options	4	
Explanation of Program Menu	5	
Example of PLU Data	6	
PLU Data Entry PLU Text Entry Mark Down Sales Mode Fixed Weight Unit Price Cost Price Tare Shelf Life Use by Date Item Code Message 1 - 6 Message 7 - 99 Pack Time Code Select Flag Code POS Code	7 - 10 10 - 11 11 12 12 12 13 13 14 14 15 15 16 16 17	Pg 7 = Delete
PLU Price Change Permanent Price Change Batch Price Change	18 - 19 20 - 22	
Programmable Text Messages	23 - 24	
Date/Time	24 - 25	
Shop Name/Address	26 - 28	

Preset Keys Programming Preset Keys Programming Tare Preset Keys	29 - 30 31
PLU File List PLU File List on Labels PLU File List on Report Paper	33 34 - 35 35
Department Name	36 - 37
Group Name	38 - 39
Advertising Message  LAMPAIGN  Totalization Mode	40 - 46 46 A-B
General	47
Production Total Operation Summary of Totalization Mode Summary of Totalization Menu's Daily Department Total Daily Group Total Daily Item Total Designated PLU Hourly Totals Accumulated Group Accumulated Item Accumulated Designated PLU	47 - 48 49 50 51 52 53 54 55 55
Production Total Clearing	56 - 57

APPENDIX A: FONTS, EXTERNAL KEYBOARD, SPECIAL CHARACTERS

C: SAMPLE LABELS



Please read the manual fully before attempting to program the AC-2000 scale.

We at Ishida strive to make certain that there are no errors in the following pages. If, however a mistake becomes apparent please contact Ishida at the previous number.

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store:

https://the-checkout-tech.com/manuals/ishida/AC-2000-PLU programming manual.html

And our free Online Keysheet maker:

https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM