



**AC-3000/3000E**

*SYSTEM SETUP MANUAL*

# Table of Contents

## 1 AC-3000 System Setup Overview

1.1 INTRODUCTION .....	1-1
1.2 PARTS REQUIRED FOR MOUNTING .....	1-2
1.3 OPTIONS .....	1-2
1.4 MASTER BOARD .....	1-3

## 2 Setup Procedures

2.1 MASTER SCALE PROCEDURES .....	2-1
2.2 SATELLITE SCALE PROCEDURES .....	2-2
2.3 MASTER BOARD (P-835) ATTACHMENT .....	2-3
2.4 I <sup>2</sup> NET CABLE CONNECTION METHOD .....	2-5
2.5 I <sup>2</sup> NET CABLE CONNECTORS .....	2-5

## 3 Test Mode Procedures

3.1 MENU SCHEMATIC .....	3-1
3.2 MENU SELECTION METHODS .....	3-2
3.3 SALES MODE (C08) .....	3-2
3.4 MASTER BOARD HARDWARE TEST (C101) .....	3-3
3.5 MASTER BOARD RAM CLEAR (C102) .....	3-4
3.6 MEMORY CHECK .....	3-4
3.7 MASTER BOARD DATA SD/LD (C199) .....	3-5

## 4 Registration Mode

4.1 SYSTEM EXPANSION MODE .....	4-1
4.2 MACHINE NO. (P17) .....	4-2
4.3 INLINE REGISTRATION (P19) .....	4-2
4.4 MASTER MAINTENANCE (P20) .....	4-3

## 5 Setup Error Messages

5.1 ERROR MESSAGE HANDLING .....	5-1
----------------------------------	-----

## 6 Electrical Diagrams

6.1 BLOCK DIAGRAM .....	6-1
6.2 CONNECTION DIAGRAM .....	6-2

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*