




System Scale Printer  
**AC-4000 Series**  
AC-4000, AC-4000B, AC-4000E

# Operator's Manual



**IMPORTANT**

- Do not carry out installation, operation, service, or maintenance until thoroughly understanding the contents of this manual.
- Keep this manual available at all times for installation, operation, service, and maintenance.

PN 80812

**ISHIDA CO., LTD.**

# CONTENTS

<b>Chapter 1</b>	<b>PRODUCT OVERVIEW</b> .....	<b>1</b>
1.1	Appearance & Display .....	2
1.2	Operation Keysheet.....	3
1.3	Basic Function Keys .....	4
1.4	Preset Function Keys .....	6
1.5	Label Loading .....	10
<b>Chapter 2</b>	<b>NORMAL MODE</b> .....	<b>15</b>
2.1	Weighing Items.....	16
2.2	Fixed Price Items.....	18
<b>Chapter 3</b>	<b>DAILY MAINTENANCE</b> .....	<b>21</b>
3.1	Cleaning .....	22
3.2	Condition Check .....	23
<b>Chapter 4</b>	<b>TROUBLE SHOOTING</b> .....	<b>25</b>
4.1	Error Codes & Messages .....	26
4.2	Other Error Conditions.....	29
4.3	Replacing the Main Fuse .....	30

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*