




# System Scale Printer **AC-4000**

## **Programmer's Manual**



### **IMPORTANT**

- Do not carry out installation, operation, service, or maintenance until thoroughly understanding the contents of this manual.
- Keep this manual available at all times for installation, operation, service, and maintenance.

PN80811

**ISHIDA CO., LTD.**

# CONTENTS

<b>Chapter 1 PRODUCT OVERVIEW .....</b>	<b>1</b>
1.1 Program Keysheet .....	2
1.2 Program Function Keys.....	3
1.3 Edit Keys .....	3
1.4 Specifications .....	5
<b>Chapter 2 SETUP MODE.....</b>	<b>7</b>
2.1 SETUP MODE ENTRY/EXIT .....	8
2.2 LABEL FORMAT (B01) .....	9
2.3 POS CODE (B02) .....	17
2.4 ITEM CODE (B03) .....	20
2.5 DEFAULT DATA (B04) .....	22
2.6 TOTAL MODE SELECT (B05) .....	25
2.7 OPEN PRICE (B07) .....	27
2.8 PLU SELECT (B08) .....	28
2.9 SYSTEM SELECT (B09).....	30
2.10 ETHERNET SETUP (B10).....	32
2.11 SYSTEM TIMER (B11).....	41
2.12 PASSWORD (B12).....	42
2.13 MACHINE NUMBER (B13) .....	44
<b>Chapter 3 REGISTRATION MODE.....</b>	<b>45</b>
3.1 REGISTRATION MODE ENTRY/EXIT .....	46
3.2 PLU FILE (P01).....	47
3.3 COMMODITY NAME (P02).....	58
3.4 PLU DELATE (P02-03) .....	59
3.5 PRICE CHANGE (P03) .....	60
3.6 PRESET KEY (P04).....	61
3.7 STORE NAME/ADDRESS (P05) .....	65
3.8 DATE/TIME (P06) .....	66
3.9 EXTRA MESSAGE 1 (P07).....	68
3.10 DEFAULT PLU (P08) .....	69
3.11 ITEM LIST MODE (P09) .....	70
3.12 RS232C MODE (P10).....	72
3.13 COUPON MESSAGE (P20).....	75
3.14 EXTRA MESSAGE 2 (P21).....	76
3.15 EXTRA MESSAGE 3 (P22).....	77
3.16 TCP/IP MODE (P23).....	78
3.17 OPERATOR NAME (P24) .....	84
3.18 TITLE DATA (P25).....	86
3.19 ADVERTISEMENT MESSAGE (P26) .....	87
3.20 DEPARTMENT CODE/NAME (P27) .....	90
3.21 GROUP CODE/NAME (P28) .....	91
3.22 CAMPAIGN ITEM (P29).....	92

<b>Chapter 4 TEXT EDITING.....</b>	<b>97</b>
4.1 Edit keys and display indicators .....	98
4.2 Text create/edit.....	102
4.3 Reverse/italic/underline/bold text .....	104
4.4 Insert/overwrite characters .....	105
4.5 Character delete.....	106
4.6 Line delete.....	107
<b>Chapter 5 TOTAL MODE .....</b>	<b>109</b>
5.1 TOTAL MODE ENTRY/EXIT .....	110
5.2 DAILY TOTAL (F01) .....	111
5.3 WEEKLY TOTAL (F02).....	114
5.4 MONTHLY TOTAL (F03).....	117
5.5 HOURLY TOTAL (F04).....	120
5.6 OPERATOR TOTAL (F05) .....	121
5.7 PERIODICAL TOTAL (F06).....	122
5.8 ERROR TOTAL (F07) .....	123
5.9 TOTAL CLEAR (F08) .....	124
5.10 ERROR TOTAL CLEAR (F09) .....	126
5.11 PAPER MODE (F10).....	127
5.12 BATCH REPORT (F11).....	128
<b>Chapter 6 SUBTRACTION MODE .....</b>	<b>129</b>
6.1 Item subtraction (D01).....	130
<b>APPENDIX .....</b>	<b>133</b>
Operator function.....	134

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/ishida/AC-4000-System programming manual.htm](https://the-checkout-tech.com/manuals/ishida/AC-4000-System%20programming%20manual.htm)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)