



**IMPORTANT**

- Do not carry out installation, operation, service, or maintenance until thoroughly understanding the contents of this manual.
- Keep this manual available at all times for installation, operation, service, and maintenance.

**ISHIDA CO., LTD.**

## CONTENTS

<b>Chapter 1 OVERVIEW .....</b>	<b>1-1</b>
1.1 FRONT VIEW.....	1-1
1.2 REAR VIEW.....	1-1
1.3 DISPLAY .....	1-2
1.4 KEY SHEET .....	1-2
1.5 SPECIFICATIONS .....	1-3
<b>Chapter 2 SETUP MODE (B mode).....</b>	<b>2-1</b>
2.1 ENTERING SETUP MODE.....	2-1
2.2 B01 LABEL FORMAT.....	2-2
2.2.1 B01-01 Print Setup.....	2-2
2.2.2 B01-02 Label Format .....	2-7
2.3 B02 BARCODE SETTING.....	2-12
2.3.1 B02-01 POS Flag.....	2-12
2.3.2 B02-02 10 Digit Flag .....	2-12
2.3.3 B02-03 Barcode Type .....	2-13
2.3.4 B02-04 POS Type .....	2-14
2.3.5 B02-05 ITF 18 Digit Barcode Type.....	2-15
2.3.6 B02-06 Manufacturer Code.....	2-15
2.3.7 Returning to B01.....	2-15
2.4 B03 BARCODE .....	2-16
2.4.1 B03-01 Item Code Position .....	2-16
2.4.2 B03-02 Department Code Position .....	2-16
2.4.3 B03-03 Group Code Position .....	2-17
2.4.4 Returning to B01.....	2-17
2.5 B04 DEFAULT SETTING.....	2-18
2.5.1 B04-01 Date Print .....	2-18
2.5.2 B04-02 Use By Days.....	2-18
2.5.3 B04-03 Pack Time Print .....	2-19
2.5.4 B04-04 Expiry Time Print .....	2-19
2.5.5 B04-05 Best Before Date Print.....	2-20
2.5.6 B04-06 Best Before Date .....	2-20
2.5.7 B04-07 Unit Type .....	2-21
2.5.8 Returning to B01.....	2-21
2.6 TOTAL MODE SELECTION.....	2-22
2.6.1 B05-01 Daily Total.....	2-22
2.6.2 B05-02 Weekly Total .....	2-22
2.6.3 B05-03 Monthly Total .....	2-23
2.6.4 Returning to B01.....	2-23
2.7 B07 OPEN PRICE .....	2-24
2.7.1 B07-01 Open Price Selection.....	2-24
2.7.2 Returning to B01.....	2-24

<b>2.8</b>	<b>PLU SELECTION.....</b>	<b>2-25</b>
2.8.1	B08-02 Sales Mode .....	2-25
2.8.2	B08-03 Unit Price.....	2-25
2.8.3	B08-04 Markdown Flag.....	2-26
2.8.4	B08-05 Markdown Price.....	2-26
2.8.5	B08-06 Fixed Weight .....	2-27
2.8.6	B08-07 Quantity.....	2-27
2.8.7	B08-08 Tare .....	2-28
2.8.8	B08-09 Date Print .....	2-28
2.8.9	B08-10 SHELF LIFE .....	2-29
2.8.10	B08-11 Best Before Date Flag .....	2-29
2.8.11	B08-12 Best Before Date Data.....	2-30
2.8.12	B08-13 Pack Time Flag.....	2-30
2.8.13	B08-14 Pack Time Data .....	2-31
2.8.14	B08-15 Expiry Time Flag.....	2-31
2.8.15	B08-16 Expiry Time Data .....	2-32
2.8.16	B08-17 Item Code.....	2-32
2.8.17	B08-18 Barcode Type .....	2-33
2.8.18	B08-19 POS Type .....	2-33
2.8.19	B08-20 POS Flag.....	2-34
2.8.20	B08-21 POS Code .....	2-34
2.8.21	B08-22 Open Price .....	2-35
2.8.22	B08-23 Commodity Message.....	2-35
2.8.23	B08-24 Ingredients Message .....	2-36
2.8.24	B08-25 Nutrition information panel Message .....	2-36
2.8.25	B08-27 Coupon Message .....	2-37
2.8.26	B08-27 Logo Image 1 .....	2-37
2.8.27	B08-28 Logo Image 2 .....	2-38
2.8.28	B08-29 Label Format Number.....	2-38
2.8.29	B08-32 Upper Limit .....	2-39
2.8.30	B08-33 Lower Limit .....	2-39
2.8.31	B08-34 Unit Type .....	2-40
2.8.32	B08-35 Department Code .....	2-40
2.8.33	B08-36 Group Code.....	2-41
2.8.34	B08-37 Register Code .....	2-41
2.8.35	B08-38 Cost Price.....	2-42
2.8.36	B08-39 POP Number .....	2-42
2.8.37	B08-41 Storage Message .....	2-43
2.8.38	B08-42 Advisory Message .....	2-43
2.8.39	B08-42 Returning to B01.....	2-43
<b>2.9</b>	<b>B09 SYSTEM .....</b>	<b>2-44</b>
2.9.1	B09-01 PLU Registration .....	2-44
2.9.2	B09-02 Commodity Name Registration.....	2-44
2.9.3	B09-04 Preset Key.....	2-45
2.9.4	B09-05 Store Name & Address .....	2-45
2.9.5	B09-06 Date and Time .....	2-46
2.9.6	B09-07 Commodity Message.....	2-46
2.9.7	B09-08 Open PLU.....	2-47
2.9.8	B09-09 Item List.....	2-47
2.9.9	B09-10 RS232C Communications .....	2-48

2.9.10	B09-20	Coupon Message .....	2-48
2.9.11	B09-21	Ingredients Message .....	2-49
2.9.12	B09-22	NIP Message .....	2-49
2.9.13	B09-23	TCP/IP Communication .....	2-50
2.9.14	B09-24	Operator System .....	2-50
2.9.15	B09-25	Title Message .....	2-51
2.9.16	B09-26	Advertisement Message .....	2-51
2.9.17	B09-27	Department.....	2-52
2.9.18	B09-28	Group .....	2-52
2.9.19	B09-29	Campaign .....	2-53
2.9.20		Returning to B01.....	2-53
2.10	B10	ETHERNET SETTINGS.....	2-54
2.10.1	B10-01	IP Address Setting.....	2-54
2.10.2	B10-02	Gateway Address Settings .....	2-55
2.10.3	B10-03	Subnet Mask .....	2-57
2.10.4	B10-04	Server Address.....	2-59
2.10.5	B10-05	Login Name Registration .....	2-60
2.10.6	B10-06	Password Registration for FTP Communication .....	2-61
2.10.7	B10-07	MAC Address .....	2-61
2.10.8	B10-08	DHCP Communication Setup .....	2-62
2.10.9	B10-09	Network Status .....	2-63
2.11	B11	SYSTEM TIMER .....	2-65
2.12	B12	PASSWORD REGISTRATION.....	2-66
2.12.1	B12-01	Password for Registration Mode .....	2-66
2.12.2	B12-02	Password for Total Mode .....	2-66
2.12.3	B12-03	Password for Subtraction Mode .....	2-67
2.12.4	B12-04	Password for Setup Mode .....	2-67
2.12.5	B12-06	Password Change .....	2-67
2.12.6		Returning to B01.....	2-67
2.13	B13	MACHINE NUMBER .....	2-69
2.14		EXITING THE MODE .....	2-70

<b>Chapter 3 TEST MODE (C mode) .....</b>	<b>3-1</b>
3.1 ENTERING TEST MODE.....	3-1
3.2 C01 HARDWARE TEST .....	3-2
3.2.1 C01-01 A/D Check .....	3-2
3.2.2 C01-02 Key Check.....	3-3
3.2.3 C01-03 Display Check .....	3-4
3.2.4 C01-04 RS232C Check .....	3-5
3.2.5 C01-05 Application Program Number .....	3-5
3.2.6 C01-06 BIOS Program Number .....	3-6
3.2.7 C01-07 Reset Count .....	3-7
3.3 C02 RAM CLEAR .....	3-8
3.3.1 C02-01 SRAM Clear .....	3-8
3.3.2 C02-02 Set Data Clear.....	3-8
3.3.3 C02-03 Test Data Clear.....	3-8
3.3.4 Returning to C01 .....	3-9

3.4	C03	THERMAL HEAD .....	3-10
3.4.1		C03-01 Thermal Head Resistance.....	3-10
3.4.2		C03-02 Print Usage Distance.....	3-10
3.4.3		C03-03 Resistance Value Adjustment .....	3-11
3.4.4		Returning to C01 .....	3-11
3.5	C04	LABEL SENSOR CHECK .....	3-12
3.5.1		C04-00 Label Sensor .....	3-12
3.5.2		Returning to C01 .....	3-12
3.6	C05	TOTAL MEMORY .....	3-13
3.6.1		C05-00 Total Memory & Remaining Memory .....	3-13
3.6.2		Returning to C01 .....	3-13
3.7	C06	ROM SWITCH .....	3-14
3.7.1		C06-00 ROM Switch Selection.....	3-14
3.7.2		Returning to C01 .....	3-15
3.8	C07	PEEL SENSOR CHECK .....	3-16
3.8.1		C07-00 Peel Sensor.....	3-16
3.8.2		Returning to C01 .....	3-16
3.8.3		Exiting the Mode.....	3-16

## **Chapter 4 COMPONENT REPLACEMENT ..... 4-1**

4.1	THERMAL HEAD REPLACEMENT .....	4-1
4.2	PRINT ROLLER REPLACEMENT .....	4-2
4.3	LOAD CELL REPLACEMENT .....	4-4
4.4	MAIN BOARD REPLACEMENT .....	4-6
4.5	KEY SHEET REPLACEMENT .....	4-8
4.6	A/D BOARD REPLACEMENT .....	4-10
4.7	POWER SUPPLY BOARD REPLACEMENT .....	4-12
4.8	DISPLAY UNIT REPLACEMENT .....	4-14

## **Chapter 5 ERROR LIST & TROUBLESHOOTING ..... 5-1**

5.1	ERROR LIST .....	5-1
5.2	TROUBLESHOOTING .....	5-2

## **Appendix ..... A-1**

A.1	BLOCK DIAGRAM .....	A-1
A.2	DISPLAY SPECIFICATIONS (L1 TYPE).....	A-2
A.3	POWER SUPPLY UNIT SPECIFICATIONS.....	A-3

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/ishida/BC-4000 service manual.html](https://the-checkout-tech.com/manuals/ishida/BC-4000%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)