




System Scale Printer BC-4000TEC

User's Manual



IMPORTANT

- Do not carry out installation, operation, service, or maintenance until thoroughly understanding the contents of this manual.
- Keep this manual available at all times for installation, operation, service, and maintenance.

ISHIDA CO., LTD.

TABLE OF CONTENTS

| | | |
|------------------|-----------------------------|------------|
| Chapter 1 | PRODUCT OVERVIEW | 1-1 |
| 1.1 | APPEARANCE & DISPLAY | 1-2 |
| 1.1.1 | APPEARANCE | 1-2 |
| 1.1.2 | DISPLAY | 1-2 |
| 1.2 | KEYSHEETS | 1-3 |
| 1.3 | BASIC OPERATION KEYS | 1-4 |
| 1.4 | PROGRAM KEYS | 1-5 |
| 1.5 | PRESET KEYS | 1-7 |
| 1.6 | SPECIFICATIONS | 1-9 |
| 1.7 | CLEANING | 1-10 |
| | | |
| Chapter 2 | DAILY OPERATION | 2-1 |
| 2.1 | LABEL SETTING | 2-2 |
| 2.2 | WEIGHING ITEMS | 2-6 |
| 2.3 | FIXED PRICE ITEMS | 2-8 |
| | | |
| Chapter 3 | SUBTRACTION MODE | 3-1 |
| 3.1 | ITEM SUBTRACTION (D01) | 3-2 |
| | | |
| Chapter 4 | TOTAL MODE | 4-1 |
| 4.1 | TOTAL MODE ENTRY/EXIT (F00) | 4-2 |
| 4.1.1 | TOTAL MODE ENTRY | 4-2 |
| 4.1.2 | TOTAL MODE EXIT | 4-2 |
| 4.2 | DAILY TOTAL (F01) | 4-3 |
| 4.3 | WEEKLY TOTAL (F02) | 4-6 |
| 4.4 | MONTHLY TOTAL (F03) | 4-9 |
| 4.5 | HOURLY TOTAL (F04) | 4-12 |
| 4.6 | OPERATOR TOTAL (F05) | 4-13 |
| 4.7 | PERIODICAL TOTAL (F06) | 4-14 |
| 4.8 | ERROR TOTAL (F07) | 4-15 |
| 4.9 | TOTAL CLEAR (F08) | 4-16 |
| 4.10 | ERROR TOTAL CLEAR (F09) | 4-18 |
| 4.11 | PAPER MODE (F10) | 4-19 |
| 4.12 | BATCH REPORT (F11) | 4-20 |

| | | |
|------------------|------------------------------|------------|
| Chapter 5 | REGISTRATION MODE | 5-1 |
| 5.1 | REGISTRATION MODE ENTRY/EXIT | 5-2 |
| 5.1.1 | MODE ENTRY | 5-2 |
| 5.1.2 | MODE EXIT | 5-2 |
| 5.2 | PLU FILE (P01) | 5-3 |
| 5.3 | COMMODITY NAME (P02) | 5-16 |
| 5.4 | PLU DELETE (P02-03) | 5-17 |
| 5.5 | PRICE CHANGE (P03) | 5-18 |
| 5.6 | PRESET KEY (P04) | 5-20 |
| 5.7 | STORE NAME/ADDRESS (P05) | 5-23 |
| 5.8 | DATE/TIME (P06) | 5-25 |
| 5.9 | EXTRA MESSAGE (P07) | 5-28 |
| 5.10 | DEFAULT PLU (P08) | 5-29 |
| 5.11 | ITEM LIST MODE (P09) | 5-30 |
| 5.12 | RS232C MODE (P10) | 5-32 |
| 5.13 | COUPON MESSAGE (P20) | 5-35 |
| 5.14 | INGREDIENTS MESSAGE (P21) | 5-36 |
| 5.15 | NIP MESSAGE (P22) | 5-37 |
| 5.16 | TCP/IP MODE (P23) | 5-38 |
| 5.17 | OPERATOR NAME (P24) | 5-44 |
| 5.18 | TITLE DATA (P25) | 5-46 |
| 5.19 | ADVERTISEMENT MESSAGE (P26) | 5-47 |
| 5.20 | DEPARTMENT CODE/NAME (P27) | 5-49 |
| 5.21 | GROUP CODE/NAME (P28) | 5-50 |
| 5.22 | CAMPAIGN ITEM (P29) | 5-51 |
| 5.23 | CAMPAIGN ITEM (P40) | 5-56 |
| | | |
| Chapter 6 | TEXT EDITING | 6-1 |
| 6.1 | TEXT EDITING | 6-2 |
| 6.1.1 | PROGRAM KEY SHEET | 6-2 |
| 6.1.2 | EDIT KEYS | 6-2 |
| 6.1.3 | DISPLAY INDICATORS | 6-4 |
| 6.1.4 | 7-SEGMENT CHARACTERS | 6-4 |
| 6.1.5 | CHARACTER FONTS | 6-5 |
| 6.2 | TEXT CREATE/EDIT | 6-6 |
| 6.3 | INSERT/OVERWRITE CHARACTERS | 6-8 |
| 6.4 | CHARACTER DELETE | 6-9 |
| | | |
| APPENDIX | | A-1 |
| A.1 | ERROR CODE & MESSAGES | A-2 |
| A.2 | COMMUNICATION PROBLEMS | A-3 |

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*