



DP-3000

Programming Manual



Contents

Chapter 1: Program Keys

1.1	Program Key Sheet	2
1.2	Program Function Keys	3
1.3	Speed Function Keys	4
1.4	Text Editing Keys	5

Chapter 2: Total Reports

2.1	Total Reports	8
2.2	Total Mode	8
2.3	Present Report	9
2.4	Daily Total Report	10
2.5	Weekly Total Report	13
2.6	Monthly Total Report	16
2.7	Hourly Total Report	19
2.8	Periodical Total Report	20
2.9	Operator Total Report	21
2.10	Week Total Report	22
2.11	Total Clear	23
2.12	Daily Total Report (Label)	24

Chapter 3: Programming

3.1	PLUs	26
3.2	Deleting PLUs	34
3.3	Price Change File	35
3.4	Extra Message File	39
3.5	Coupon Message File	41
3.6	Date and Time	43
3.7	Store Names and Addresses	44
3.8	Preset Keys	46
3.9	Printing PLU/Message Information	48
3.10	Department Codes and Names	50

3.11	Group Codes and Names	52
3.12	Operator Codes and Names	54
3.13	Advertisement Messages	56
3.14	Campaign Files	59
3.15	Other Programming	61
3.16	Setting On-line/Off-line	63
3.17	Master File Downloading	64
3.18	Nutrition Files	67
3.19	Changing Unit Price/Fixed Price	73
3.20	Label Format Selection	74

Chapter 4: Text Editing

4.1	7-Segment Indicators	76
4.2	Character Size	76
4.3	Text Editing Keys	77
4.4	How to Create/Edit Text	78
4.5	How to Reverse Text	79
4.6	How to Change Characters	81
4.7	How to Change Characters	82
4.8	How to Delete Characters	83

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/ishida/DP-3000 programming manual.html](https://the-checkout-tech.com/manuals/ishida/DP-3000%20programming%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)