


## **BATTERY DRIVEN SCALE**

INS-100

## Operator's Manual



## **IMPORTANT**

- Do not carry out installation, operation, service, or maintenance until thoroughly understanding the contents of this manual.
- Keep this manual available at all times for installation, operation, service, and maintenance.

ISHIDA CO., LTD.

## **TABLE OF CONTENTS**

| Chapter   | PRODUCT OVERVIEW   | 1  |
|---|--|--|
| 1.1 N   | MAIN COMPONENTS & DISPLAY  | 2  |
| 1.1   |  | 2  |
| 1.1   | I.2 DISPLAY  |  |
| 1.2 k   | (EYBOARD   | 3  |
| 1.2   | 2.1 KEY LAYOUT   | 3  |
| 1.2   | 2.1 KEY FUNCTIONS  | 3  |
| 1.3 F   | POWER SUPPLY   | 4  |
| 1.3   | 3.1 DC POWER SUPPLY  | 4  |
| 1.3   | 3.2 AC POWER SUPPLY  | 4  |
| 1.4   | SPECIFICATIONS   | 5  |
|   |  |  |
| Chapter 2   | WEIGHING OPERATIONS  | 7  |
| -   | WEIGHING OPERATIONSLEVEL ADJUSTMENT  |  |
| 2.1   |  | 8  |
| 2.1   | LEVEL ADJUSTMENTPOWER ON/OFF   | 8<br>9                                     |
| 2.1<br>2.2<br>2.2   | LEVEL ADJUSTMENTPOWER ON/OFF   | 8<br>9                                     |
| 2.1<br>2.2<br>2.2<br>2.2                                    | LEVEL ADJUSTMENT   | 8<br>9<br>9<br>10                          |
| 2.1<br>2.2<br>2.2<br>2.2                                    | LEVEL ADJUSTMENT POWER ON/OFF 2.1 POWER ON 2.2 POWER OFF TARE SUBTRACTION 3.1 WEIGHING TARE  | 8<br>9<br>9<br>10                          |
| 2.1<br>2.2<br>2.2<br>2.2<br>2.3<br>2.3                      | LEVEL ADJUSTMENT POWER ON/OFF 2.1 POWER ON 2.2 POWER OFF TARE SUBTRACTION 3.1 WEIGHING TARE 3.2 KEYBOARD TARE  | 8<br>9<br>9<br>10<br>10                    |
| 2.1<br>2.2<br>2.2<br>2.3<br>2.3<br>2.3<br>2.3               | LEVEL ADJUSTMENT POWER ON/OFF 2.1 POWER ON 2.2 POWER OFF TARE SUBTRACTION 3.1 WEIGHING TARE 3.2 KEYBOARD TARE WEIGHING SINGLE COMMODITY  | 8<br>9<br>9<br>10<br>10<br>11              |
| 2.1<br>2.2<br>2.2<br>2.3<br>2.3<br>2.3<br>2.4<br>2.5        | LEVEL ADJUSTMENT POWER ON/OFF 2.1 POWER ON 2.2 POWER OFF TARE SUBTRACTION 3.1 WEIGHING TARE 3.2 KEYBOARD TARE WEIGHING SINGLE COMMODITY WEIGHING SINGLE COMMODITY WITH TARE                                    | 8<br>9<br>10<br>10<br>11<br>12             |
| 2.1<br>2.2<br>2.2<br>2.3<br>2.3<br>2.3<br>2.4<br>2.5<br>2.6 | LEVEL ADJUSTMENT  POWER ON/OFF  2.1 POWER ON  2.2 POWER OFF  TARE SUBTRACTION  3.1 WEIGHING TARE  3.2 KEYBOARD TARE  WEIGHING SINGLE COMMODITY  WEIGHING SINGLE COMMODITY WITH TARE  RANDOM WEIGHING ADDITIONS | 8<br>9<br>10<br>10<br>11<br>12<br>14       |
| 2.1<br>2.2<br>2.2<br>2.3<br>2.3<br>2.3<br>2.4<br>2.5        | LEVEL ADJUSTMENT POWER ON/OFF 2.1 POWER ON 2.2 POWER OFF TARE SUBTRACTION 3.1 WEIGHING TARE 3.2 KEYBOARD TARE WEIGHING SINGLE COMMODITY WEIGHING SINGLE COMMODITY WITH TARE                                    | 8<br>9<br>10<br>10<br>11<br>12<br>14<br>16 |

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store:

https://the-checkout-tech.com/manuals/ishida/INS-100 operators manual.html

And our free Online Keysheet maker:

https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM